

ASSEMBLY INSTRUCTIONS COASTER FINE FURNITURE



Fine Furniture for every stage of life

753518 Coffee Table

ITEM: 753518



ASSEMBLY INSTRUCTIONS

ASSEMBLY TIPS:

- 1. Remove hardware from box and sort by size.
- 2. Please check to see that all hardware and parts are present prior to start of assembly.
- 3. Please follow attached instructions in the same sequence as numbered to assure fast & easy assembly.



WARNING!

- 1. Don't attempt to repair or modify parts that are broken or defective. Please contact the store immediately.
- 2. This product is for home use only and not intended for commercial establishments.



ASSEMBLY TIME

15 MINUTES

PARTS IDENTIFICATION

A TOP



1PC

B LEG

(M8 - BLK)



4PCS


HARDWARE IDENTIFICATION

1	BOLT (JCBB M8 X 70mm)	8PCS
2	ALLEN WRENCH (M5 - BLK)	1PC
3	LOCK WASHER (M8 - BLK)	8PCS
4	FLAT WASHER	8PCS


ITEM:**753518**



ASSEMBLY INSTRUCTIONS STEP 1




STEP 2 COMPLETE





ITEM:**753518**





Note: Dimension tolerance ±5%