

ASSEMBLY INSTRUCTIONS
COASTER FINE FURNITURE



Fine Furniture for every stage of life

709687
END TABLE

ITEM:709687



ASSEMBLY INSTRUCTIONS

ASSEMBLY TIPS:

1. Remove hardware from box and sort by size.
2. Please check to see that all hardware and parts are present prior to start of assembly.
3. Please follow attached instructions in the same sequence as numbered to assure fast & easy assembly.




WARNING!

1. Don't attempt to repair or modify parts that are broken or defective. Please contact the store immediately.
2. This product is for home use only and not intended for commercial establishments.

ASSEMBLY TIME 10 MINUTES


PARTS IDENTIFICATION

A GLASS




1PC

B BASE



1PC

C POST



1PC

HARDWARE IDENTIFICATION

Z

1 BOLT
(1/4" x 12mm BLK)



3PCS

2 ALLEN WRENCH
(4mm)




1PC

ITEM: 709687 ASSEMBLY INSTRUCTIONS




STEP 1


Do not tighten until each step is completed or instructed.



STEP 2



COMPLETE




ITEM: 709687

ASSEMBLY INSTRUCTIONS



Product Size : 597 DIA X 616 H (MM)
Product Size : 23.5" DIA X 24.25"



Note : Dimension tolerance $\pm 5\%$