

ASSEMBLY INSTRUCTION







DINING CHAIR

1420S








Caution: Please read instructions thoroughly before unpacking assembly parts. Sharp, exposed staple tips can cause injury, therefore, for your protection, please remove any exposed staples used in packing.

1. We recommend that you should assemble this product with the assistance of another person, this will make assembly easier, and will help to eliminate damage to the product or injury to persons during assembly.
2. Be sure to check all packing materials carefully for small parts that may have come loose inside the carton during shipment.
3. Please put all parts on a non-abrasive floor before assembly, and follow the assembly steps to assemble your newly purchased product correctly and efficiently.
4. Please do not fully tighten any screws or bolts until last step.
5. Periodically check to ensure that all connectores (bolts,screw,etc) are tight.

PART LIST

No.	PART	DESCRIPTION	Q'TY
A		CHAIR BACK	1
B		SEAT CUSHION	1
C		LEFT FRONT LEG	1
D		RIGHT FRONT LEG	1
E		LEFT STRETCHER	1
F		RIGHT STRETCHER	1


HARDWARE LIST

No.	PART	DESCRIPTION	Q'TY
1		BOLT Φ5/16"X83MM	4
2		BOLT Φ5/16"X57MM	4
3		BOLT Φ5/16"X45MM	2
4		LOCK WASHER Φ5/16"X13MM	10
5		FLAT WASHER Φ5/16"X19MM	10
6		ALLEN KEY M5 X 65MM	1
7		SCREW M4X38MM	4




Only tighten all bolts when all bolts aligned with bolt inserts.

TOOLS REQUIRED (NOT PROVIDED)




Phillips Screw Driver


STEP 1




STEP 2



STEP 3



STEP 4: Completed



NOTE : Periodically check to ensure that all connectors (bolt, screws, etc.) are tight.