

## 191565 Assembly Instructions





## **Hardware Components**

This bag contains small parts that present a chocking hazard for children under three years of age. These parts are for adult assembly only and should be permanently affixed to the furniture.


Any unused parts should be discarded properly.







2.



3.

