F HOOKER ASSEMBLY INSTRUCTION

ITEM: 7050-75203B-02 Round Pedestal Dining Table Base 7050-75203B-89 Round Pedestal Dining Table Base 7050-75203T-02 Round Pedestal Table Top w/1-22in leaf 7050-75203T-89 Round Pedestal Table Top w/1-22in leaf

Thank you for purchasing this quality product. Be sure to unpack carefully looking for small parts which may have come loose during shipment.

Read all instruction and study the drawing carefully before starting the assembly process.

HARDWARE PACK					PART LIST			
NO.	DRAWING	DESCRIPTION	SIZE	Q'TY	NO.	DRAWING	DESCRIPTION	Q'TY
А		Allen Wrench	5mm	1pc	1	\diamond	Leaf	1PC
В		Bolt	<u>5</u> " 16	4pcs	2	8	Base	1PC
С	Ø	Lock Washer	<u>5</u> " 16	4pcs	3	\bigotimes	Тор	1PC
D	0	Flat Washer	<u>5</u> " 16	4pcs				

STEP 1



Attach Base (2) to table top (3).



Adjust leveler if needed to level table on uneven floor.



ASSEMBLY INSTRUCTION

ITEM: 7050-75203B-02 Round Pedestal Dining Table Base 7050-75203B-89 Round Pedestal Dining Table Base 7050-75203T-02 Round Pedestal Table Top w/1-22in leaf 7050-75203T-89 Round Pedestal Table Top w/1-22in leaf



Instruction for table leaves:

- 1. There are latches at the bottom of table top, unlock the latches as shown in Diagram 1 above.
- 2. Pull out table top as the arrow direction shown in Diagram 2.
- 3. Place table leaf (1) between table tops and push table tops together.
- 4. Lock the latches (See Diagram 1).
- 5. Take opposite actions to remove table leaf.