




CHLOE FULL/QUEEN/KING BED

ASSEMBLY INSTRUCTIONS



PARTS AND FITTING PACKAGING DETAIL


<p>BOX #1 A. HEADBOARD 1 PC</p> 	<p>BOX #2 B. FOOTBOARD 1 PC F. SLAT ROLL 1 SET</p> 	<p>BOX #3 C. SIDE RAILS 2 PCS D. CENTER SUPPORT 1 PC E. SUPPORT LEGS 3 PCS</p> 
--	---	--




HARDWARE PACKED IN BOX #2

H1	ALL THREAD BOLT (M8x60)		8
H2	HEX NUT (M8)		8
H3	LOCK WASHER (M10)		8
H4	ARC WASHER		8
H5	WRENCH		1
H6	WOOD SCREW (M4x25)		6

TOOL REQUIRED: PHILLIPS HEAD SCREW DRIVER (NOT PROVIDED)



STEP 1




CHLOE FULL/QUEEN/KING BED


ASSEMBLY INSTRUCTIONS



STEP 2



STEP 3




CHLOE FULL/QUEEN/KING BED

ASSEMBLY INSTRUCTIONS

MODUS
FURNITURE

STEP 4




INSTRUCTIONS FOR ADJUSTING LEVELERS:

Position the bed in your room.
Locate levelers under each leg support.

Turn counter-clockwise to extend,
clockwise to contract.

Adjust levelers until each leg support is
applying equal upward pressure on the
bed slat.



MAINTENANCE INSTRUCTION:




- Remove box spring and mattress before moving your bed
- Lift your bed when moving it. Dragging can damage leg support.
- Readjust levelers after moving your bed.

CHLOE CAL KING BED

ASSEMBLY INSTRUCTIONS




PARTS AND FITTING PACKAGING DETAIL

<p>BOX #1 A. HEADBOARD 1 PC</p> 	<p>BOX #2 B. FOOTBOARD 1 PC F. SLAT ROLL 1 SET</p> 	<p>BOX #3 C. SIDE RAILS 2 PCS D. CENTER SUPPORT 1 PC E. SUPPORT LEGS 3 PCS</p> 
--	---	--




HARDWARE PACKED IN BOX #2			
H1	ALL THREAD BOLT (M8x60)		8
H2	HEX NUT (M8)		8
H3	LOCK WASHER (M10)		8
H4	ARC WASHER		8
H5	WRENCH		1
H6	WOOD SCREW (M4x25)		6

TOOL REQUIRED: PHILLIPS HEAD SCREW DRIVER (NOT PROVIDED)




STEP 1




CHLOE CAL KING BED

ASSEMBLY INSTRUCTIONS

STEP 2



STEP 3




CHLOE CAL KING BED

ASSEMBLY INSTRUCTIONS

MODUS
FURNITURE

STEP 4




INSTRUCTIONS FOR ADJUSTING LEVELERS:

Position the bed in your room.
Locate levelers under each leg support.

Turn counter-clockwise to extend,
clockwise to contract.

Adjust levelers until each leg support is
applying equal upward pressure on the
bed slat.



MAINTENANCE INSTRUCTION:

- Remove box spring and mattress before moving your bed
- Lift your bed when moving it. Dragging can damage leg support.
- Readjust levelers after moving your bed.