

ASSEMBLY INSTRUCTIONS

MODEL #

CM4192-C


Questions?

GIVE US A CALL: 1-888-980-5122 MON – FRI 8:30AM – 5:30PM (PT)

TOOLS REQUIRED



Allen Wrench





2 - People Recommended



The Assembly Rating is a 5-point system showing the level of effort needed to assemble a specific product.

VERSION # 22-05-18






Thank you for your purchase!

We hope you enjoy this new addition to your home for many years to come.

Our commitment to providing quality products does not simply end when you purchase our product. We fully stand behind our products from start to finish. Our customer service department is available Monday – Friday 8:30 AM – 5:30 PM Pacific Time and can help with assembly questions as well as, if necessary, replacing damaged or missing parts. To help expedite our service, please have these assembly instructions readily available, along with your order receipt.



PRE ASSEMBLY

We understand building ready-to-assemble furniture can be a challenging experience for some. To help avoid confusion, we have provided some helpful tips that may speed up the process.


















Teamwork

ALWAYS have at least two people to help with transporting and assembling the product to avoid potential injury and/or damage.

Suitable Location

Assembling near the area of the intended location is highly recommended.

Sufficient Space

Make sure you have enough space to move around during the assembly.

Avoid Scratches

Use cardboard, blankets or a carpeted area while assembling furniture to prevent to prevent scratches and damages.


Flat Surface

Make sure the furniture rests on a flat and level surface with each leg evenly touching the floor.

ASSEMBLY AND CARE ADVICE



FAILURE TO FOLLOW THE GUIDELINES BELOW MAY RESULT IN INJURY AND/OR PROPERTY DAMAGE.





maintenance.

After two weeks, check and tighten any loose hardware and repeat again every six months thereafter.


IT IS THE USER'S RESPONSIBILITY TO MAINTAIN THE FURNITURE. THE HARDWARE MAY LOOSEN OVER TIME AND MAY CAUSE THE FURNITURE TO BE WOBBLY AND UNABLE TO SUPPORT ITS INTENDED WEIGHT CAPACITY. THIS MAY LEAD TO COLLAPSE AND MAY CAUSE SERIOUS INJURY.

COFFEE TABLE

CM4192-C

Please keep instructions for future reference.

 Check the quantity and irregularity of parts and hardware before you start.



PARTS (#1) 1pc #2 1pc ()...()Support Leg Glass Top HARDWARE #C 3pcs #A 3pcs (#B)3pcs Bolt M6x426mm Flat washer Ø3/4" Bolt M6 (#D)6pcs 1pc (**#E**) Adjust Ø1/2" Allen wrench


CM4192-C is packed in 2 cases

Carton	Designation	Part	Hardware
СМ4192-С-1	Glass		
CM4192-C-2	Leg		#A 3pcs Bolt M6x426mm #B 3pcs Bolt M6 #C 3pcs Doft M6 #C 3pcs Doft M6 #C 3pcs Doft Flat washer Ø3/4" #D 6pcs Doft Adjust Ø1/2" #E 1pc Allen wrench

ASSEMBLY INSTRUCTIONS

1


Part #1) × 1pc Hardware #A × 3pcs



ASSEMBLY INSTRUCTIONS



Part (#1) ×1pc Part (#2) × 1pc Hardware (#A) ×3pcs Hardware (#B) ×3pcs Hardware (#C) ×3pcs Hardware (#D) ×6pcs Hardware (#E) ×1pc



3

