



ASSEMBLY INSTRUCTIONS
COASTER FINE FURNITURE



Fine Furniture for every stage of life

722207
END TABLE

REVISION 0 : 12/16/2020

PAGE 1 OF 6

COASTERFURNITURE.COM

ITEM:722207



ASSEMBLY INSTRUCTIONS

ASSEMBLY TIPS:

1. Remove hardware from box and sort by size.
2. Please check to see that all hardware and parts are present prior to start of assembly.
3. Please follow attached instructions in the same sequence as numbered to assure fast & easy assembly.



WARNING!


1. Don't attempt to repair or modify parts that are broken or defective. Please contact the store immediately.
2. This product is for home use only and not intended for commercial establishments.

ASSEMBLY TIME 40 MINUTES

PARTS IDENTIFICATION

A


TOP



1PC

B


UPPER LEG FRAME



1PC

C

LOWER LEG FRAME



1PC

D

LEG



4PCS

E

SHELF









1PC

ITEM:722207



ASSEMBLY INSTRUCTIONS

HARDWARE IDENTIFICATION

1	BOLT (1/4" x 12mm BLK)		9PCS
2	LONG BOLT (ϕ 1/4" x 127mm BLK)		4PCS
3	CAP (20 x 40mm BLK)		4PCS
4	L BRACKET (27 x 27mm)		4PCS
5	WASHER		4PCS
6	ALLEN KEY (4mm)		1PC


ITEM: 722207





ASSEMBLY INSTRUCTIONS

STEP 1

Do not tighten until each step is completed or instructed.




STEP 2



ITEM: 722207

ASSEMBLY INSTRUCTIONS

STEP 3




ITEM:722207

ASSEMBLY INSTRUCTIONS



Product Size : DIA 584 X 591 H (MM)

Product Size : DIA 23" X 23.25"



Note : Dimension tolerance $\pm 5\%$