



# Assembly Instruction

Loveseat


ITEM NO.: 9627CAF-2/9627TAN-2



Legs & hardware are packed in the box and stored under the seat cushion, please take out for assembly.

Note: Do not use power tools for assembly. Power tools increase the risk of over tightening which lead to splitting or cracking the wood.


## Component list

No	Drawing	Qty	Description
<b>A</b>		<b>1</b>	<b>Love seat</b>
<b>B</b>		<b>2</b>	<b>Seat cushions</b>
<b>C</b>		<b>2</b>	<b>Pillows (17"*17")</b>
<b>D</b>		<b>4</b>	<b>Wooden legs (Ø55*Ø45*195mm)</b>
<b>E</b>		<b>12</b>	<b>Bolt 25mm (1/4*25mm)</b>
<b>F</b>		<b>1</b>	<b>Allen key (M4*59mm)</b>


THE PARTS ARE LOCATED INSIDE THE BOX AS BELOW:

**WOODEN LEGS**


**HARDWARE**




**WOODEN LEGS AND  
HARDWARE STORE  
UNDER THE SEAT  
CUSHION**



## Step #1




## Step #2



### Step #3

Assembly completed.



## Care Instruction for fabric Furniture:

In order to maintain the original appearance of your Textured Microfiber fabric, please follow below simple care procedures:

- Avoid exposing furniture directly to sunlight or heating and air conditioning outlets. Sunlight and/or exposure to heating and air conditioning outlets will fade/damage fabrics. Do not place your upholstered furniture too close to windows, radiators, or vents, and be sure to use windows, radiators, or vents.
- Vacuum or wipe with a soft cloth to remove dust.
- Hardware may loosen over time. Periodically check to make sure all connections are tight. Re-tighten if necessary.



For items use on wooden floor, hard surfaces or carpets, it is recommended to Install protective pads under all legs and supports to avoid/prevent from damages/scratches and discoloration.