

CLA-418-272 CHITTER CHATTER

CARACOLE CLASSIC

ASSEMBLY INSTRUCTIONS

PLEASE UNPACK ALL PARTS AND CHECK QUANTITY AGAINST PARTS LIST BEFORE DISCARDING PACKING CARTON!

1) Assemble the chair back(1) and the chair seat(2) together with the wrench(G), the flat washer(E), the spring washer(F) and the screw(A).

2) Assemble the rear leg of the chair back(1) and the chair seat(2) with the wrench(G), the flat washers(E), the spring washers(F) and screws(B).

3) Assemble the left arm & leg(3) / right arm & leg(4) and the seat front(2) with the wrench(G), the flat washers(E), the spring washers(F) and nuts(D).





4) Secure the left arm & leg(3) / right arm & leg(4) and the chair back assembly(1) with the screws(C).








Note: The screw driver for this step is not included in the hardware bag.


5) Tighten the assembly and put it upright.


*** NOTE KEEP THIS SHEET ***

In the unlikely event that you would need a replacement part for your furniture, please contact your local authorized Schnadig International dealer. If you need replacement hardware quickly, it could be purchased from your local hardware store.


CLA-418-272				
CHITTER CHATTER				
Part List				
NO.	Hardware List		Part Number	QTY
①		Chair Back	CLA-418-272-062	1
②		Chair Seat	CLA-418-272-061	1
③		Left Arm & Leg Assembly	CLA-418-272-063	1
④		Right Arm & Leg Assembly	CLA-418-272-064	1

RTA Hardware				
Hardware List				QTY
A		Screw	5/16"x1-3/4"	1
B		Screw	5/16"x2-1/2"	4
C		Screw	1/4"x1-1/2"	2
D		Nut	5/16"	4
E		Flat Washer	5/16"	9
F		Spring Washer	5/16"	9
G		Wrench	5/16"	1





STEP 1



STEP 2