



SAMSUNG




BN68-18041A-00


Unpacking and Installation Guide
Guide de déballage et d'installation
Guía de desembalaje e instalación
Manual de desempacotamento e instalação
Auspacken und Installationsanleitung
Guida al disimballaggio e all'installazione
Руководство по распаковке и установке
Қаптамадан шығару және орнату нұсқаулығы
Посібник з розпаковки та встановлення
Qadoqdan chiqarish va o'rnatish qo'llanmasi




1




2




3




4




5




6






7




8





	A	B	C	D	E	F	G	H
77S9*D	67.7 inches	38.9 inches	1.8 inches	41.7 inches	14.1 inches	76.8 inches	76.7 lbs	80.7 lbs
77SD9*	(1718.5 mm)	(987.6 mm)	(44.9 mm)	(1058.6 mm)	(359.0 mm)	(195 cm)	(34.8 kg)	(36.6 kg)
	(171.85 cm)	(98.76 cm)	(4.49 cm)	(105.86 cm)	(35.90 cm)	(19.5 cm)	(34.8 кг)	(36.6 кг)

* : 0~9, A~Z



	VESA A x B (mm) VESA A x B (mm)	C (mm) C (mm)	D x 4
77S9*D 77SD9*	400 x 300	28-30	M8

* : 0~9, A~Z