

ASSEMBLY INSTRUCTIONS

MODEL #

CM3145T


Questions?

GIVE US A CALL: 1-888-980-5122 MON-FRI 8:30AM - 5:30PM (PT)

TOOLS REQUIRED




(Included)





2 - People Recommended

ASSEMBLY RATING



The Assembly Rating is a 5-point system showing the level of effort needed to assemble a specific product.






Thank you for your purchase!

We hope you enjoy this new addition to your home for many years to come.

Our commitment to providing quality products does not simply end when you purchase our product. We fully stand behind our products from start to finish. Our customer service department is available Monday – Friday 8:30 AM – 5:30 PM Pacific Time and can help with assembly questions as well as, if necessary, replacing damaged or missing parts. To help expedite our service, please have these assembly instructions readily available, along with your order receipt.



PRE ASSEMBLY INTRODUCTION

We understand building ready-to-assemble furniture can be a challenging experience for some. To help avoid confusion, we have provided some helpful tips that may speed up the process.


















Avoid Scratches

Use cardboard, blankets or a carpeted area while assembling furniture to prevent to prevent scratches and damages.

Flat Surface

Make sure the furniture rests on a flat and level surface with each leg evenly touching the floor.

ALWAYS have at least two people

Teamwork

to help with transporting and assembling the product to avoid potential injury and/or damage.

Suitable Location

Assembling near the area of the intended location is highly recommended.


Sufficient Space

Make sure you have enough space to move around during the assembly.

ASSEMBLY AND CARE ADVICE



FAILURE TO FOLLOW THE GUIDELINES BELOW MAY RESULT IN INJURY AND/OR PROPERTY DAMAGE.



Save the instructions and store any supplied tools for later maintenance.


After two weeks, check and tighten any loose hardware and repeat again every six months thereafter.


IT IS THE USER'S RESPONSIBILITY TO MAINTAIN THE FURNITURE. THE HARDWARE MAY LOOSEN OVER TIME AND MAY CAUSE THE FURNITURE TO BE WOBBLY AND UNABLE TO SUPPORT ITS INTENDED WEIGHT CAPACITY. THIS MAY LEAD TO COLLAPSE AND MAY CAUSE SERIOUS INJURY.




 Please keep instructions for future reference.

Check the quantity and irregularity of parts and hardware before you start.





Exploded View



CM3145T is packed in 2 cases


Carton	Disignation	Part		Hardware
CM3145T-1	Table Top	#1		 #A x 12pcs #B x 14pcs #C x 6pcs #D x 32pcs #E x 32pcs #F x1pc
	Leaf (2pcs)	#2		
	Plate (2pcs)	#6		
CM3145T-2	Base (2pcs)	#3		
	Pedestal (2pcs)	#4		
	Feet (6pcs)	#5	CT CT CT CT CT CT	

ASSEMBLY INSTRUCTIONS

Align feet (#5) to the pedestal (#4), then




Part #4 x1pc Part #5 x3pcs Hardware #A x3pcs Hardware #C x3pcs Hardware #D x6pcs Hardware #E x6pcs



2

Part #3 x1pc Hardware #A x3pcs Hardware #D x3pcs Hardware #E x3pcs Align pedestal to the base (#3), then secure by using bolts (#A) with washers (#D,E).





x 2

ASSEMBLY INSTRUCTIONS

3

Part (#6) x1pc Hardware (#B) x3pcs Hardware (#D) x3pcs Hardware (#E) x3pcs





ASSEMBLY INSTRUCTIONS

