


# ASSEMBLY INSTRUCTIONS COASTER FINE FURNITURE



*Fine Furniture for every stage of life*

**223264**  
**Mirror**

ITEM:223264

ASSEMBLY INSTRUCTIONS


ASSEMBLY TIPS:

- 1.Remove hardware from box and sort by size.
- 2.Please check to see that all hardware and parts are present prior to start of assembly.
- 3.Please follow attached instructions in the same sequence as numbered to assure fast & easy assembly.

WARNING!



- 1.Don't attempt to repair or modify parts that are broken or defective. Please contact the store immediately.
- 2.This product is for home use only and not intended for commercial establishments.




ASSEMBLY TIME

10 MINUTES


PARTS IDENTIFICATION

A  
DRESSER  
FROM BOX  
ITEM 223263




1PC

C  
MIRROR SUPPORT  
(PACKED WITH  
DRESSER)



2PCS


B  
MIRROR



1PC


HARDWARE IDENTIFICATION

1  
BOLT  
(1/4" x 32mm - BLK)



6PCS

3  
FLAT WASHER  
(1/4" x 19 x 1.5mm - BLK)




6PCS

2  
LOCK WASHER  
(1/4" - BLK)



6PCS

4  
ALLEN WRENCH  
(4MM - BLK)




1PC



ITEM: **223264**

**ASSEMBLY INSTRUCTIONS**


**STEP 1**



**STEP 2**  
**COMPLETE**



ITEM:223264



Note: Dimension tolerance  $\pm 5\%$