



ASSEMBLY INSTRUCTIONS

COASTER FINE FURNITURE



Fine Furniture for every stage of life

106381(B1&B2)

Dining Table

REVISION 0: 07/02/2015
REVISION 1: 12/15/2020

PAGE 1 OF 4

COASTERFURNITURE.COM

ITEM:106381(B1&B2)



ASSEMBLY INSTRUCTIONS


ASSEMBLY TIPS:

1. Remove hardware from box and sort by size.
2. Please check to see that all hardware and parts are present prior to start of assembly.
3. Please follow attached instructions in the same sequence as numbered to assure fast & easy assembly.



WARNING!

1. Don't attempt to repair or modify parts that are broken or defective. Please contact the store immediately.
2. This product is for home use only and not intended for commercial establishments.




ASSEMBLY TIME

30 MINUTES

PARTS IDENTIFICATION

B1 (BOX 1)

A TOP



1PC

B TRESTLE BAR



1PC

B2 (BOX 2)

C LEG



2PCS

HARDWARE IDENTIFICATION

Z-B2 (BOX 2) - HARDWARE PACK IS LOCATED IN 106381 (B2)

1 ALLEN WRENCH
(M4 X 110MM - BLK)



1PC

2 LONG BOLT
(M6 x 50MM - RBW)



2PCS

3 SHORT BOLT
(M6 X 30MM - RBW)



4PCS

4 LOCK WASHER
(1/4" - BLK)



14PCS



5 FLAT WASHER
(M6 x 13MM - RBW)



14PCS

STEP 1


Unscrew short bolt to detach plywood from table leg.
(Please keep the short bolt to be use in STEP 3)

**STEP 2**



ITEM: **106381(B1&B2)**




STEP 3



STEP 4 **COMPLETE**



ITEM: **106381(B1&B2)**



Note: Dimension tolerance $\pm 5\%$



ASSEMBLY INSTRUCTIONS

COASTER FINE FURNITURE



Fine Furniture for every stage of life

106382
Side Chair

REVISION 0: 09/08/2017
REVISION 1: 02/14/2020
REVISION 2: 02/14/2023

PAGE 1 OF 4

COASTERFURNITURE.COM

ITEM: **106382**



ASSEMBLY INSTRUCTIONS


ASSEMBLY TIPS :

1. Remove hardware from box and sort by size.
2. Please check to see that all hardware and parts are present prior to start of assembly.
3. Please follow attached instructions in the same sequence as numbered to assure fast & easy assembly.



WARNING !





1. Don't attempt to repair or modify parts that are broken or defective. Please contact the store immediately.
2. This product is for home use only and not intended for commercial establishments.



ASSEMBLY TIME

30 MINUTES

PARTS IDENTIFICATION

A	BACK FRAME		1PC
B	FRONT LEG FRAME		1PC
C	SIDE RAIL		2PCS
DF	SEAT CUSHION		1PC

HARDWARE IDENTIFICATION

1	ALLEN WRENCH (M4 x 100MM - BLK)		1PC
2	BOLT (M6 x 50MM - RBW)		6PCS
3	LOCK WASHER (1/4" - BLK)		6PCS
4	FLAT WASHER (M6 x 13MM - RBW)		6PCS
5	PAN HEAD SCREW (#8 x 1 1/4" -BLK)		4PCS

NOTE :


Phillips head screw driver is required in the assembly process. However, manufacturer does not provide this item. Quantities shown are for one chair.

ITEM: **106382**


ASSEMBLY INSTRUCTIONS



STEP 1




STEP 2





ITEM: **106382**

ASSEMBLY INSTRUCTIONS


STEP 3



STEP 4 COMPLETE



ITEM: **106382**



Note: Dimension tolerance $\pm 5\%$