



# *ASSEMBLY INSTRUCTIONS*

## *COASTER FINE FURNITURE*



*Fine Furniture for every stage of life*

**100770**  
***Dining Table***

REVISION 0: 01/10/2006  
REVISION 1: 03/19/2012  
REVISION 2: 11/26/2012  
REVISION 3: 09/06/2018  
REVISION 4: 07/13/2020

**PAGE 1 OF 5**

COASTERFURNITURE.COM

ITEM: **100770**



## ASSEMBLY INSTRUCTIONS


### ASSEMBLY TIPS :

1. Remove hardware from box and sort by size.
2. Please check to see that all hardware and parts are present prior to start of assembly.
3. Please follow attached instructions in the same sequence as numbered to assure fast & easy assembly.



### WARNING !

1. Don't attempt to repair or modify parts that are broken or defective. Please contact the store immediately.
2. This product is for home use only and not intended for commercial establishments.



ASSEMBLY TIME

10 MINUTES

## PARTS IDENTIFICATION

A	TOP		1PC
B	LEG		4PCS
C	LEAF		1PC
D	APRON		2PCS

## HARDWARE IDENTIFICATION


1	<b>WRENCH</b> (12.8MM - RBW )		1PC
2	<b>ALLEN WRENCH</b> ( M4 x 63MM - BLK )		1PC
3	<b>HEX NUT</b> (5/16" - RBW )		8PCS
4	<b>LOCK WASHER</b> ( 5/16" -RBW )		8PCS
5	<b>FLAT WASHER</b> ( 5/16" -RBW )		8PCS
6	<b>BOLT</b> ( M6 x 60MM -BLK )		4PCS

ITEM: **100770**


## ASSEMBLY INSTRUCTIONS



### STEP 1



### STEP 2




ITEM: **100770**


## ASSEMBLY INSTRUCTIONS



### STEP 3



### STEP 4




ITEM: **100770**


## ASSEMBLY INSTRUCTIONS




### STEP 5



### STEP 6 COMPLETE



ITEM: **100770**



**Note: Dimension tolerance  $\pm 5\%$**



# *ASSEMBLY INSTRUCTIONS*

## *COASTER FINE FURNITURE*



*Fine Furniture for every stage of life*

**100773**  
***Dining Side Chair***

REVISION 0: 01/10/2006  
REVISION 1: 02/17/2012  
REVISION 2: 07/13/2020

ITEM: **100773**



## ASSEMBLY INSTRUCTIONS


### ASSEMBLY TIPS :

1. Remove hardware from box and sort by size.
2. Please check to see that all hardware and parts are present prior to start of assembly.
3. Please follow attached instructions in the same sequence as numbered to assure fast & easy assembly.



### WARNING !





1. Don't attempt to repair or modify parts that are broken or defective. Please contact the store immediately.
2. This product is for home use only and not intended for commercial establishments.







ASSEMBLY TIME

10 MINUTES

## PARTS IDENTIFICATION

A	BACK FRAME		1PC
B	FRONT LEG FRAME		1PC
C	SIDE RAIL		2PCS
D	SEAT CUSHION		1PC

## HARDWARE IDENTIFICATION

1	ALLEN WRENCH ( M4 x 110MM - BLK )		1PC
2	BOLT ( M6 x 50MM - RBW )		6PCS
3	LOCK WASHER ( 1/4" - BLK )		6PCS
4	PAN HEAD SCREW ( #8 x 1" -BLK )		4PCS

### NOTE :


Phillips head screw driver is required in the assembly process ; However, manufacturer not provide this item.  
Quantities shown are for one chair.




ITEM: **100773**  
**ASSEMBLY INSTRUCTIONS**



**STEP 1**




**STEP 2**





ITEM: **100773**

## ASSEMBLY INSTRUCTIONS


### STEP 3



### STEP 4 **COMPLETE**



ITEM: **100773**



**Note: Dimension tolerance  $\pm 5\%$**