

ASSEMBLY INSTRUCTIONS COASTER FINE FURNITURE



Fine Furniture for every stage of life

193611(B1&B2) *Dining Table*

REVISION 0: 01/10/2025

PAGE 1 OF 5

COASTER*

ASSEMBLY INSTRUCTIONS


ASSEMBLY TIPS:

- 1. Remove hardware from box and sort by size.
- 2. Please check to see that all hardware and parts are present prior to start of assembly.
- 3. Please follow attached instructions in the same sequence as numbered to assure fast & easy assembly.



WARNING!

- 1. Don't attempt to repair or modify parts that are broken or defective. Please contact the store immediately.
- 2. This product is for home use only and not intended for commercial establishments.



ASSEMBLY TIME

10 MINUTES

PARTS IDENTIFICATION

B1 (BOX 1)

A TOP WITH LEAF

1PC

B2 (BOX 2)

B LEG PANEL SUPPORT

C MOUNTING BOARD

2PCS

D LEG PANEL

2PCS

HARDWARE IDENTIFICATION

Z-B1(BOX 1) - HARDWARE PACK IS LOCATED IN 193611 (B1)


1	BOLT WITH SMALL WASHER (M6 x 40mm - BLK)	4PCS
2	BOLT WITH BIG WASHER (M6 x 40mm - BLK)	12PCS
3	ALLEN WRENCH (M4 x 55mm - GD)	1PC

COASTER


ASSEMBLY INSTRUCTIONS

STEP 1

IMPORTANT NOTE: Take out the Extension Leaf.



STEP 2




PAGE 3 OF 5




STEP 3

Do not fully tighten until all bolts are attached.



STEP 4


Fully tighten all bolts on this step.




Turn counter-clockwise to unlock



STEP 5




STEP 6 COMPLETE









Note: Dimension tolerance ±5%



ASSEMBLY INSTRUCTIONS COASTER FINE FURNITURE



Fine Furniture for every stage of life

193611(B1&B2) *Dining Table*

REVISION 0: 01/10/2025

PAGE 1 OF 5

COASTER*

ASSEMBLY INSTRUCTIONS


ASSEMBLY TIPS:

- 1. Remove hardware from box and sort by size.
- 2. Please check to see that all hardware and parts are present prior to start of assembly.
- 3. Please follow attached instructions in the same sequence as numbered to assure fast & easy assembly.



WARNING!

- 1. Don't attempt to repair or modify parts that are broken or defective. Please contact the store immediately.
- 2. This product is for home use only and not intended for commercial establishments.



ASSEMBLY TIME

10 MINUTES

PARTS IDENTIFICATION

B1 (BOX 1)

A TOP WITH LEAF

1PC

B2 (BOX 2)

B LEG PANEL SUPPORT

C MOUNTING BOARD

2PCS

D LEG PANEL

2PCS

HARDWARE IDENTIFICATION

Z-B1(BOX 1) - HARDWARE PACK IS LOCATED IN 193611 (B1)


1	BOLT WITH SMALL WASHER (M6 x 40mm - BLK)	4PCS
2	BOLT WITH BIG WASHER (M6 x 40mm - BLK)	12PCS
3	ALLEN WRENCH (M4 x 55mm - GD)	1PC

COASTER


ASSEMBLY INSTRUCTIONS

STEP 1

IMPORTANT NOTE: Take out the Extension Leaf.



STEP 2




PAGE 3 OF 5




STEP 3

Do not fully tighten until all bolts are attached.



STEP 4


Fully tighten all bolts on this step.




Turn counter-clockwise to unlock



STEP 5




STEP 6 COMPLETE









Note: Dimension tolerance ±5%



ASSEMBLY INSTRUCTIONS COASTER FINE FURNITURE




Fine Furniture for every stage of life

193612 Side Chair

ASSEMBLY INSTRUCTIONS

ASSEMBLY TIPS:



- 2. Please check to see that all hardware and parts are present prior to start of assembly.
- 3. Please follow attached instructions in the same sequence as numbered to assure fast & easy assembly.



WARNING!

- 1. Don't attempt to repair or modify parts that are broken or defective. Please contact the store immediately.
- 2. This product is for home use only and not intended for commercial establishments.



ASSEMBLY TIME

10 MINUTES

PARTS IDENTIFICATION

A	BACK FRAME		1PC
В	SEAT CUSHION WITH FRAME		1PC
С	LEFT FRONT LEG	B 1 0	1PC
D	RIGHT FRONT LEG	(R)	1PC
E	SIDE STRETCHER	(D	2PCS

HARDWARE IDENTIFICATION

1	LONG BOLT WITH WASHER (M6 x 90mm - BLK)		4PCS
2	MEDIUM BOLT WITH WASHER (M6 x 60mm - BLK)		4PCS
3	SHORT BOLT WITH WASHER (M6 x 50mm - BLK)		3PCS
4	PAN HEAD SCREW (M5 x 38mm - BLK)	() , , , , , , , , , , , , , , , , , , ,	4PCS
5	ALLEN WRENCH (M4 x 55mm - GD)		1PC

NOTE:


Quantities shown are for one chair.

Phillips head screw driver is required in the assembly process; however, manufacturer does not provide this item.


ASSEMBLY INSTRUCTIONS

FINE FURNITURE

STEP 1




STEP 2




ASSEMBLY INSTRUCTIONS

COASTER FINE FURNITURE

STEP 3




STEP 4 COMPLETE









Note: Dimension tolerance ±5%