

ASSEMBLY INSTRUCTIONS COASTER FINE FURNITURE



Fine Furniture for every stage of life

980074 WALL SHELF

ASSEMBLY INSTRUCTIONS



ASSEMBLY TIPS:

- 1. Remove hardware from box and sort by size.
- 2. Please check to see that all hardware and parts are present prior to start of assembly.
- 3. Please follow attached instructions in the same sequence as numbered to assure fast & easy assembly.



WARNING!

- 1. Don't attempt to repair or modify parts that are broken or defective. Please contact the store immediately.
- 2. This product is for home use only and not intended for commercial establishments.



ASSEMBLY TIME

40 MINUTES

PARTS IDENTIFICATION

A	TOP LEFT POST	1 PC
В	TOP RIGHT POST	IPC
С	BOTTOM POST	2 PCS
D	SHELF	4 PCS
E	BOTTOM FRAME	1 PC
F	TOP PANEL	1 PC
G	BACK PANEL	1 PC
Н	LEFT PANEL	1 PC
I	RIGHT PANEL	1 PC

PAGE 2 OF 13

COASTERFURNITURE.COM

ASSEMBLY INSTRUCTIONS



PARTS IDENTIFICATION

J	BOTTOM PANEL	1 PC
К	LARGE DRAWER FRONT PANEL	1 PC
L	LARGE DRAWER LEFT SIDE PANEL	1 PC
М	LARGE DRAWER RIGHT SIDE PANEL	1 PC
N	LARGE DRAWER BACK PANEL	1 PC
0	LARGE DRAWER BOTTOM PANEL	1 PC
Р	SMALL DRAWER BOTTOM PANEL	1 PC
Q	SMALL DRAWER FRONT PANEL	1 PC
R	SMALL DRAWER LEFT SIDE PANEL	1 PC
S	SMALL DRAWER RIGHT SIDE PANEL	1 PC
т	SMALL DRAWER BACK PANEL	1 PC
U	HANGING FILE BAR	3 PCS



ASSEMBLY INSTRUCTIONS

Z HARDWARE IDENTIFICATION

1	SHORT BOLT (1/4" x 15mm - BLK)		24 PCS
2	SHORT PAN HEAD SCREW (Ø8 x 26mm - BLK)		2 PCS
3	LONG PAN HEAD SCREW (Ø8 x 52mm - BLK)		2 PCS
4	FLAT WASHER (Ø12 x 1mm - BLK)		2 PCS
5	FLAT HEAD SCREW (Ø7 x 28mm - BLK)	8) months	16 PCS
6	PLASTIC ANCHOR (Ø14 x 43mm - WHT)	ODD	4 PCS
7	LONG BOLT (1/4" x 28mm - BLK)		4 PCS
8	FLAT WASHER (Ø16 x 2mm - BLK)		4 PCS
9	LOCK WASHER (Ø10.7 x 1.5mm - BLK)		4 PCS


ASSEMBLY INSTRUCTIONS



Z HARDWARE IDENTIFICATION


10	CAM BOLT (Ø6.5 x 33mm - SR)	8 PCS
11	CAM NUT (Ø15 x 12mm - SR)	4 PCS
12	CAM NUT (Ø11.7 x 10.5mm - SR)	4 PCS
13	WOOD DOWEL (Ø8 x 30mm)	2 PCS
14	WOOD DOWEL (Ø7 x 25mm)	6 PCS
15	HANDLE (137 x 30 x 10mm - BLK)	2 PCS
16	HANDLE WITH SCREW (Ø8.5 x 25mm - BLK)	4 PCS
17	ALLEN WRENCH (4mm x 108mm - SR)	1 PC
18	LEVELER (Ø24 x 22mm - BLK)	2 PCS


ITEM:980074 COASTER® FINE FURNITURE **ASSEMBLY INSTRUCTIONS** STEP 1 В С (a) 9 STEP 2 M 16 16 Κ 15



COASTER

ASSEMBLY INSTRUCTIONS STEP 3






ASSEMBLY INSTRUCTIONS

STEP 5








PAGE 8 OF 13


COASTERFURNITURE.COM

ASSEMBLY INSTRUCTIONS STEP 6













STEP 12 COMPLETE









Note: Dimension tolerance ±5%