

E-Commerce by Enitial Lab

ASSEMBLY INSTRUCTIONS

MODEL #

CM-BK970

Questions?

GIVE US CALL: 1-888-980-5122 MON-FRI 8:30AM - 5:30PM (PST)

TOOLS REQUIRED



Allen Wrench




Phillips Screwdriver (Not Included)



2 - People Recommended

ASSEMBLY RATING



The Assembly Rating is a 5-point system showing the level of effort needed to assemble a specific product.








Thank you for your purchase!

We hope you enjoy this new addition to your home for many years to come.

Our commitment to providing quality products does not simply end when you purchase our product. We fully stand behind our products from start to finish. Our customer service department is available Monday – Friday 8:30 AM – 5:30 PM Pacific and can help with assembly questions as well as, if necessary, replacing damaged or missing parts. To help expedite our service, please have these assembly instructions readily available, along with your order receipt.



PRE ASSEMBLY

We understand building ready-to-assemble furniture can be a challenging experience for some. To help avoid confusion, we have provided some helpful tips that may speed up the process.




















Teamwork

ALWAYS have at least two people to help with transporting and assembling the product to avoid potential injury and/or damage.

Suitable Location

Assembling near the area of the intended location is highly recommended.

Sufficient Space

Make sure you have enough space to move around during the assembly.

Avoid Scratches

Use cardboard, blankets or a carpeted area while assembling furniture to prevent scratches.

Flat Surface

Make sure the furniture rests on a flat and level surface with each leg evenly touching the floor.

ASSEMBLY AND CARE ADVICE




FAILURE TO FOLLOW THE GUIDELINES BELOW MAY RESULT IN INJURY AND/OR PROPERTY DAMAGE.




Position each part correctly and insert screws or bolts into their respective holes.



Use the appropriate hand tools or power tools for assembly. Select steps, such as tightening screws and/or bolts, may require hand tools to avoid causing damage during assembly.




Turn clockwise to tighten and only tighten when step is completed or when instructed to do so.




Save the instructions and store any supplied tools for later maintenance.

After two weeks, check and tighten any loose hardware and repeat again every six months thereafter.


IT IS THE USER'S RESPONSIBILITY TO MAINTAIN THE FURNITURE. THE HARDWARE MAY LOOSEN OVER TIME AND MAY CAUSE THE FURNITURE TO BE WOBBLY AND UNABLE TO SUPPORT ITS INTENDED WEIGHT CAPACITY. THIS MAY LEAD TO COLLAPSE AND MAY CAUSE SERIOUS INJURY.







CM-BK970 is packed in 5 cases

Carton	Disignation	Part		Hardware
CM-BK970-1	Left Headboard	#3		
	Right Headboard	#4		-
	Slat (13pcs)	#5		
CM-BK970-2	Short Guadrail	#1		CM-BK970-2
	Long Guadrail	#2		() #A x 8pcs () #B x 9pcs
	Font Side Rail	#6		#C x 1pc
	Guadrail Support	#7		() #E x 8pcs
	Guadrail Support	#8		#F x 12pcs
	Back Side Rail	#14		@ xuuuuu⊳ #G x 6pcs
	Right Ladder Rail	#10		ர்க்கை #H x 6pcs ராண்கை #I x 8pcs
	Ladder Rung	#11	DDDD	0 #K x 6pcs
	Left Ladder Rail	#12		#L x 4pcs
CM-BK970-3	Bookcase	#9		
CM-BK970-4	Left Frame	#15	E	
	Right Frame	#16	E	CM-BK970-4
	Back Rail	#17		#C x 1pc
	Top Panel	#18	\sim	#M x 8pcs
	Shelf Panel	#19	\bigcirc	#N x 8pcs
CM-BK970-5	Chest	#13		#O x 20pcs











Hardware #H x2pcs Hardware #K x2pcs




8

Part #5 x1set Hardware #D x26pcs





Align slats (#5) to the bed, then secure by using screws (#D).



10

9





information for future reference **Lift, don't drag!** To avoid damage to product

To avoid damage to product please always LIFT the product when transporting of adjusting the placement.

SAFETY WARNING

To help prevent serious or fatal injuries from entrapment or falls

. Follow the information on the warnings appearing on the upper bunk bed structure and on thi carton. Do not remove warning label from the bed.

. Always use the recommended type and size mattress or mattress support, or both, to help prevent the likehood of entrapment or falls.

. Periodically check and ersure that the guardrail, ladder, and other components are in their proper position, free from damage, and that all connectors are tight.

. Never allow a child under 6 years of age to use the upper bunk.

. Use only mattress which is 74"-75" long and 38-1/2" wide on upper bunk.

. Ensure thickness of mattress for upper bunk does not exceed 6". Thicknes of mattress for lower bunk is from 6".

. Surface of mattress must be at least 5 in. (127mm) below the upper edge of guardrails.

- . Prohibit horseplay on or under bed (s)
- . Prohibit more than one person on upper bunk.
- . Prohibit humping on the bed.
- . Always use the ladder for entering and leaving the upper bunk.
- . Do not use substitute parts. Contact the dealer for replacement parts.

. Use of a night light may provide added safety precaution for a child using the upper bunk.

. Always use guardrails on both long sides of the upper bunk. If the bunk bed will be placed next to the wall. The guardrail that runs the full length of the bed shuold be placed against the wall to prevent entrapment between the bed and wall.

. The use of water or sleep flotation mattresses is prohibited.

- . Do not exceed 175 lbs on upper bunk.
- . Weight limitation: 175lbs.

STRANGUILATION HAZARD – Never attach or hang items to any part of the

bunk bed that are not desinged for use with the bed for example, but not limited to hooks, belts and jump ropes

Keep these instructions for future reference



E-Commerce by Enitial Lab

ASSEMBLY INSTRUCTIONS



CM-BK970-4

Questions?

GIVE US CALL: 1-888-980-5122 MON-FRI 8:30AM - 5:30PM (PST)

TOOLS REQUIRED




(Included)




2 - People Recommended

ASSEMBLY RATING



The Assembly Rating is a 5-point system showing the level of effort needed to assemble a specific product.








Thank you for your purchase!

We hope you enjoy this new addition to your home for many years to come.

Our commitment to providing quality products does not simply end when you purchase our product. We fully stand behind our products from start to finish. Our customer service department is available Monday – Friday 8:30 AM – 5:30 PM Pacific and can help with assembly questions as well as, if necessary, replacing damaged or missing parts. To help expedite our service, please have these assembly instructions readily available, along with your order receipt.



PRE ASSEMBLY INTRODUCTION

We understand building ready-to-assemble furniture can be a challenging experience for some. To help avoid confusion, we have provided some helpful tips that may speed up the process.


















Avoid Scratches

assembly.

Use cardboard, blankets or a carpeted area while assembling furniture to prevent scratches.

Flat Surface

Make sure the furniture rests on a flat and level surface with each leg evenly touching the floor.

Teamwork

Suitable Location

Assembling near the area of the intended location is highly recommended.

ALWAYS have at least two people to help with transporting and assembling the product to avoid potential injury and/or damage.

Sufficient Space

Make sure you have enough space to move around during the



ASSEMBLY AND **CARE ADVICE**




FAILURE TO FOLLOW THE GUIDELINES BELOW MAY **RESULT IN INJURY AND/OR PROPERTY DAMAGE.**




Position each part correctly and insert screws or bolts into their respective holes.




Use the appropriate hand tools



Turn clockwise to tighten and only tighten when step is completed or when instructed to do so.




or power tools for assembly. Select steps, such as tightening screws and/or bolts, may require hand tools to avoid causing damage during assembly.



Save the instructions and store any supplied tools for later maintenance.


After two weeks, check and tighten any loose hardware and repeat again every six months thereafter.


IT IS THE USER'S RESPONSIBILITY TO MAINTAIN THE FURNITURE. THE HARDWARE MAY LOOSEN OVER TIME AND MAY CAUSE THE FURNITURE TO BE WOBBLY AND UNABLE TO SUPPORT ITS INTENDED WEIGHT CAPACITY. THIS MAY LEAD TO COLLAPSE AND MAY CAUSE SERIOUS INJURY.




5/8

Exploded View







5

