


ASSEMBLY INSTRUCTIONS

MODEL#


CM4568C

Questions?

GIVE US A CALL: 1-888-980-5122 MON-FRI 8:30AM - 5:30PM (PT)



TOOLS REQUIRED



(Included)



(Not Included)



Socket Wrench

(Included)



2 - People Recommended

ASSEMBLY RATING



- DIFFICULT

The Assembly Rating is a 5-point system showing the level of effort needed to assemble a specific product.





Thank you for your purchase!

We hope you enjoy this new addition to your home for many years to come.

Our commitment to providing quality products does not simply end when you purchase our product. We fully stand behind our products from start to finish. Our customer service department is available Monday – Friday 8:30 AM – 5:30 PM Pacific Time and can help with assembly questions as well as, if necessary, replacing damaged or missing parts. To help expedite our service, please have these assembly instructions readily available, along with your order receipt.



Consumer Hotline Toll-Free 1-888-980-5122



WEBSITE www.foagroup.com







foagroup



Monday to Friday 8:30AM- 5:30PM (PT)



E-MAIL cs.ec@foagroup.com



FurnitureOfAmerica



Are you missing anything? Double-check all parts, hardware and accessories listed are all acccounted for.	Check out our Quick Tips! We recommend reviewing the pre-assembly handouts. Even experts need a refresher now and then!
Should we send any replacements? Are there any irregularities or flaws in the parts? We can send replacements!	Prep Time! Please review the assembly instructions and all diagrams prior to assembling.

PRE ASSEMBLY INTRODUCTION

We understand building ready-to-assemble furniture can be a challenging experience for some. To help avoid confusion, we have provided some helpful tips that may speed up the process.





Teamwork

ALWAYS have at least two people to help with transporting and assembling the product to avoid potential injury and/or damage.





Suitable Location

Assembling near the area of the intended location is highly recommended.





Sufficient Space

Make sure you have enough space to move around during the assembly.





Avoid Scratches

Use cardboard, blankets or a carpeted area while assembling furniture to prevent to prevent scratches and damages.





Flat Surface

Make sure the furniture rests on a flat and level surface with each leg evenly touching the floor.

ASSEMBLY AND CARE ADVICE




FAILURE TO FOLLOW THE GUIDELINES BELOW MAY RESULT IN INJURY AND/OR PROPERTY DAMAGE.




Position each part correctly and insert screws or bolts into their respective holes.




Use the appropriate hand tools or power tools for assembly. Select steps, such as tightening screws and/or bolts, may require hand tools to avoid causing damage during assembly.



Turn clockwise to tighten and only tighten when step is completed or when instructed to do so.



Save the instructions and store any supplied tools for later maintenance.



After two weeks, check and tighten any loose hardware and repeat again every six months thereafter.


IT IS THE USER'S RESPONSIBILITY TO MAINTAIN THE FURNITURE. THE HARDWARE MAY LOOSEN OVER TIME AND MAY CAUSE THE FURNITURE TO BE WOBBLY AND UNABLE TO SUPPORT ITS INTENDED WEIGHT CAPACITY. THIS MAY LEAD TO COLLAPSE AND MAY CAUSE SERIOUS INJURY.

COFFEE TABLE

CM4568C




- · Please keep instructions for future reference.
- Check the quantity and irregularity of parts and hardware before you start.




PARTS





Glass

#2 1pc




Box

#3) 1pc



Left Upright Board

1pc



Bottom Board

(#5) 2pcs




Connection

COFFEE TABLE

CM4568C



- Please keep instructions for future reference.
- Check the quantity and irregularity of parts and hardware before you start.



HARDWARE

#A 4pcs

#B 2pcs

#C 6pcs

#D 2pcs

(a)

Bolt 1/4" x 1-3/8" Rod 1/4" x 3-1/8"

0

Washer Ø16xØ7x1.0 Nut M6

#E) 2pcs

(#F) 2pcs

#G 4pcs

#H) 4pcs

9

Hammer Nut

Set Screw Ø6x30 Screw M5 x 15

Sucker

(#I)6pcs

Adjustable Foot

(#J) 1pc



Socket Wrench M6

#K) 2pcs



Ø20 Sealing Sticker

#L) 1pc


Allen Wrench M4


CM4568C Points 2 cartons

Carton	Designation	Part		Hardware	
	Glass	#1			
CM4568C-1	Box	#2			
	Left Upright Board	#3			
	Bottom Board	#4		0	#A x 4pcs
				0	#B x 2pcs
				0	#C x 6pcs
					#D x 2pcs
				3	#E x 2pcs
CM4568C-2					#F x 2pcs
	Connection	#5	x2	>	#G x 4pcs
					#H x 4pcs
					#I x 6pcs
					#J x 1pc
				0	#K x 2pcs
					#L x 1pc

ASSEMBLY INSTRUCTIONS


1 Exploded View





ASSEMBLY INSTRUCTIONS

Connect threaded bolts (#B) to barrel nuts (#E) through the upright board (#3). Attach dowels (#F) onto the upright board (#3).





ASSEMBLY INSTRUCTIONS

5


Part #1) x 1pc Hardware #H) x 4pcs

Attach suckers (#H) to the connections (#5), then place glass (#1) onto the top.





6



ASSEMBLY COMPLETED



Please ensure the furniture rests on an even and flat surface. If the product wobbles or feels loose, double-check all bolts and/or screws are properly tightened and secured.

✓ Keep this handy!

Please retain this instruction manual and any order-related information for future reference.

✓ Lift, don't drag!

To avoid damage to product please always LIFT the product when transporting of adjusting the placement.