ASSEMBLY INSTRUCTIONS

Model : AVEENA-WHT-EU 76 W/TV LIFT LED & SPKR Description : Fireplace cabinet

Thank you for purchasing this quality product. Be sure to check all packing materials carefully for small parts, which may have come loose inside the carton during shipment

Bluetooth Connection: Enable Bluetooth on your device and pair with HugeSun2000-2 from the list of available devices.

PARTS LIST			
No.	Description	Diagram	Quantity
A	Fireplace cabinet		1pc
B	Faux Crystal		1 Box

HARDWARE LIST				
No.	Description	Diagram	Size	Quantity
1		Furniture tipping restraint		1Set

WARNING-Death or serious injury may occur when children climb on audio and/or video equipment furniture. A remote control or toys placed on the furnishing may encouragea child to climb on the furnishing and as a result the furnishing may tip over on to the child."

WARNING- Relocating audio and/or video equipment to furniture not specifically designed to support audio and/or video equipment may result in death or serious injury due to the furnishing collapsing or over turning onto the child."

Manufactured by SEN CHENG WOOD CO., LTD

Address: LOT N6, ROAD N3, NAM TAN UYEN INDUSTRIALZONE EXTEND, BINH CO WARD, HO CHI MINH CITY, VIETNAM.

WARNING- For use with televisions weighing 150lbs/68.04Kgs or less.Use with heavier televisions may result in instability causing tip over resulting indeath or serious injury.

Plasma/LCD-flat panel TV screen of various screen size to a maximum TV screen size 75 inches.

Each shelf should not be loaded more than 25lbs/11.34Kgs.

DO NOT EXCEED RECOMMENDED LOAD. Use with products heavier than the maximum sizes and weights indicated may result in instability causing possible injury.

Do not allow children under 16 years to move unit

Always place TV no more than two inches from the back edge of the console.

Placing TV more than two inches from the back edge may increase the risk that the console will tip over.


DO NOT REMOVE THIS LABEL

ASSEMBLY INSTRUCTIONS


Model : AVEENA-WHT-EU 76 W/TV LIFT LED & SPKR Description : Fireplace cabinet

Thank you for purchasing this quality product. Be sure to check all packing materials carefully for small parts, which may have come loose inside the carton during shipment

Step: 1 Take out the styrofoam from back side



Step: 2 Remove the fixing two bolts on the left and right sides of the unit, remove the front panel and take the accessories(B) out of the Firebox..




ASSEMBLY INSTRUCTIONS

Model : AVEENA-WHT-EU 76 W/TV LIFT LED & SPKR Description : Fireplace cabinet


Thank you for purchasing this quality product. Be sure to check all packing materials carefully for small parts, which may have come loose inside the carton during shipment

Step: 3 Place faux crystals (B) into the carbon bed of electric insert (A)



Step: 4 Install the front panel.

Carefully set both hooks of the front panel in the insert.
Hooks snap down to confirm that the insert and front panel are grouped in place .
Fasten the front panel and firebox by two bolts .
Fireplace assembly completed



ASSEMBLY INSTRUCTIONS

Model : AVEENA-WHT-EU 76 W/TV LIFT LED & SPKR


Description : Fireplace cabinet

Thank you for purchasing this quality product. Be sure to check all packing materials carefully for small parts, which may have come loose inside the carton during shipment


Step: 5 Connect the two adapter (WW) and (CC) to the power cables of the LED light and speaker, then plug them into the power. Press the button on the right side of the cabinet to turn the light on/off. The speaker is connected via Bluetooth.

Steps to Connect to speaker:

1. Plug in the Bluetooth speaker
2. Open Bluetooth settings on your phone
3. Search for devices: your phone will show a list of nearby devices
4. Tap the name of speaker: HugeSun2000-2
5. Confirm pairing
6. Play audio



Step: 6 Move the fireplace plug from behind the wood and plug in





ASSEMBLY INSTRUCTIONS

Model : AVEENA-WHT-EU 76 W/TV LIFT LED & SPKR Description : Fireplace cabinet

Thank you for purchasing this quality product. Be sure to check all packing materials carefully for small parts, which may have come loose inside the carton during shipment


Step: 7 Insert the battery with the button side into the battery bracket, making sure the battery is firmly seated





Step: 8
1. Remove the tipping restraint hardware from product
2. Move the unit into desired position
3. mark the wall with a suitable scribe the position of the fixing holes.
Warning: Before drilling, check wall for hidden pipes and cables.
4. Use the screws to secure tipping restraint hardware.

Note: To hide the straps behind the cabinet, drill the holes lower than the top of the cabinet.



ASSEMBLY INSTRUCTIONS

Model : AVEENA-WHT-EU 76 W/TV LIFT LED & SPKR Description : Fireplace cabinet

Thank you for purchasing this quality product. Be sure to check all packing materials carefully for small parts, which may have come loose inside the carton during shipment

2.4G Pairing between remote and control box

Operation instruction as follow:

Step 1: Power on the control box (preparation: power on after all parts are connected). At this time, the control box enters the pairing mode and the time is 60S.

Note: If the remote and control box do not enter the second step after 60 seconds, remove the power supply and wait until 60 seconds to power it on again (Step 1).

Step 2: Pick up the remote with the battery installed and long press 

+ 

buttons at the same time and hold for more than 3 seconds until you hear a "beep" from the control box, indicating successful pairing. Otherwise, repeat all the steps above.

Note: If the remote control is lost, replace the new remote control and repeat the above step 1. and Step 2..

S-15wireless remote 

Operation instruction

1: Preparation: According to the specification connect all parts then power on

2: Instruction of wireless remote S-15:

Install the dry-cell battery in the wireless remote, and pair it according to " Pairing between remote and control box", and then following up the operations as below, then the system can be performed normally after completion

●Up: short press 

button, the lift frame automatically moves up. Short press button again to stop

●Down: short press 

button, the lift frame automatically moves down, short press button again to stop.

●Stop: Short press 

button, the lift frame stop at once.

●When a button is pressed, the backlight lights up. The backlight will automatically turn off about 3 seconds after all keys are released.

ELECTRIC FIREPLACE

Model No.: ZHX-36-029

Room Heaters

Made in China

This device complies with part 15 of the FCC Rules. Operation is subject to the following two conditions:
(1) This device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.



CAUTION
RISK OF ELECTRIC SHOCK
DO NOT OPEN
NO USER-SERVICEABLE
PARTS INSIDE
120V - 60Hz 1500W



SEE OWNERS MANUAL FOR SERVICE DETAILS
USE ONLY ON 15 AMP BRANCH CIRCUIT.

CAUTION: RISK OF FIRE. DO NOT OPERATE UNLESS INSTALLED IN AN APPROVED CABINET.

CAUTION: HIGH TEMPERATURE, KEEP ELECTRIC CORDS, DRAPERY, AND OTHER FURNISHINGS AT LEAST 3 FEET (0.9M) FROM FRONT OF THE HEATER AND AWAY FROM THE SIDE AND REAR.

CHIMENEA ELÉCTRICA

Modelo N.º: ZHX-36-029

Calefactores de habitación

Hecho en China

Este dispositivo cumple con la parte 15 de las normas de la FCC. El funcionamiento está sujeto a las siguientes dos condiciones:
(1) Este dispositivo no debe causar interferencias perjudiciales, y (2) este dispositivo debe aceptar cualquier interferencia recibida, incluida la que pueda causar un funcionamiento no deseado.



PRECAUCIÓN
RIESGO DE DESCARGA ELÉCTRICA
NO ABRIR
NO HAY PIEZAS REPARABLES
POR EL USUARIO EN EL INTERIOR
120V-60Hz 1500W



CONSULTE EL MANUAL DEL PROPIETARIO PARA OBTENER DETALLES DE SERVICIO.
UTILICE SOLO EN UN CIRCUITO DERIVADO DE 15 AMPERIOS.
PRECAUCIÓN: RIESGO DE INCENDIO. NO OPERE A MENOS QUE ESTÉ INSTALADO EN UN GABINETE APROBADO.
PRECAUCIÓN: ALTA TEMPERATURA. MANTENGA LOS CABLES ELÉCTRICOS, CORTINAS Y OTROS MUEBLES A UNA DISTANCIA MÍNIMA DE 3 PIES (0,9 M) DEL FRENTE DEL CALEFACTOR Y ALEJADOS DE LOS LADOS Y LA PARTE TRASERA.