

## ASSEMBLY INSTRUCTIONS COASTER FINE FURNITURE



Fine Furniture for every stage of life



REVISION: 07/24/2024

PAGE 1 OF 5

COASTERFURNITURE.COM

## ITEM: 306051KE

### COASTER FINE FURNITURE

### **ASSEMBLY INSTRUCTIONS**

#### **ASSEMBLY TIPS:**

- 1. Remove hardware from box and sort by size.
- 2. Please check to see that all hardware and parts are present prior to start of assembly.
- 3. Please follow attached instructions in the same sequence as numbered to assure fast & easy assembly.



#### WARNING!

1. Don't attempt to repair or modify parts that are broken or defective. Please contact the store immediately.

2. This product is for home use only and not intended for commercial establishments.



#### NOTE:

Phillips head screw driver is required in the assemply process; however, manufacturer does not provide this item.

## ITEM: 306051KE ASSEMBLY INSTRUCTIONS



STEP 1



# ITEM: 306051KE ASSEMBLY INSTRUCTIONS



STEP 3



STEP 4



# ITEM: 306051KE ASSEMBLY INSTRUCTIONS



## STEP 5



## STEP 6 COMPLETE





PAGE 5 OF 5

COASTERFURNITURE.COM



COASTERFURNITURE.COM