


ASSEMBLY INSTRUCTIONS COASTER FINE FURNITURE



Fine Furniture for every stage of life

707897 *END TABLE*

REVISION 0: 12/04/2024

PAGE 01 OF 06

COASTERFURNITURE.COM

ASSEMBLY INSTRUCTIONS



ASSEMBLY TIPS:

- 1. Remove hardware from box and sort by size.
- 2. Please check to see that all hardware and parts are present prior to start of assembly.
- 3. Please follow attached instructions in the same sequence as numbered to assure fast & easy assembly.



WARNING!


- 1. Don't attempt to repair or modify parts that are broken or defective. Please contact the store immediately.
- 2. This product is for home use only and not intended for commercial establishment.



ASSEMBLY TIME

10 MINUTE

PARTS IDENTIFICATION



HARDWARE IDENTIFICATION

1	BOLT (1/4"x5/8")	9PCS	4	GLASS PAD (ø12mm)	4PCS
2	BOLT (1/4"x1-3/4")	4PCS	5	ALLEN KEY (4x22x60mm)	1PC
3	WASHER (¢16mm)	13PCS			


COASTER*

ASSEMBLY INSTRUCTIONS

STEP 1:


ASSEMBLY

Do not fully tighten all bolts until assembly is complete. This will help all parts to assemble properly.



STEP 2:






ASSEMBLY INSTRUCTIONS


STEP 3:








STEP 4:






ASSEMBLY INSTRUCTIONS

STEP 5:








STEP 6:







ASSEMBLY INSTRUCTIONS








STEP 8:








Note: Dimension tolerance ±5%



ASSEMBLY INSTRUCTIONS COASTER FINE FURNITURE



Fine Furniture for every stage of life

707898 *COFFEE TABLE*

REVISION 0: 01/13/2025

PAGE 01 OF 08

COASTERFURNITURE.COM

ASSEMBLY INSTRUCTIONS



ASSEMBLY TIPS:

- 1. Remove hardware from box and sort by size.
- 2. Please check to see that all hardware and parts are present prior to start of assembly.
- 3. Please follow attached instructions in the same sequence as numbered to assure fast & easy assembly.



WARNING!


- 1. Don't attempt to repair or modify parts that are broken or defective. Please contact the store immediately.
- 2. This product is for home use only and not intended for commercial establishment.



ASSEMBLY TIME

15 MINUTE

PARTS IDENTIFICATION



HARDWARE IDENTIFICATION

1	BOLT (1/4"x1/2")	8PCS
2	SCREW (M4x22mm)	4PCS
3	WASHER (¢12mm)	4PCS
4	GLASS PAD (ø12mm)	3PCS
5	ALLEN KEY (4x22x60mm)	1PC

NOTE:

Phillips head screw driver is required in the assembly process; however, manufacturer does not provide this item.


ASSEMBLY INSTRUCTIONS

COASTER FINE FURNITURE


STEP 1:


ASSEMBLY


Do not fully tighten all bolts until assembly is complete. This will help all parts to assemble properly.




STEP 2:










STEP 6:









STEP 10:






STEP 12:







Note: Dimension tolerance ±5%