

ASSEMBLY INSTRUCTIONS
COASTER FINE FURNITURE



Fine Furniture for every stage of life

104601(B1&B2)
Dining Table

ITEM: 104601(B1&B2)

ASSEMBLY INSTRUCTIONS

ASSEMBLY TIPS:

1. Remove hardware from box and sort by size.
2. Please check to see that all hardware and parts are present prior to start of assembly.
3. Please follow attached instruction in the same sequence as numbered to assure fast and easy assembly.



WARNING !

1. Don't attempt to repair or modify parts that are broken or defective. Please contact the store immediately.
2. This product is for home use only and not intended for commercial establishment.




ASSEMBLY TIME

20 MINUTES

PARTS IDENTIFICATION


B1 (BOX 1)

A TOP



1PC

B MOUNTING PLATE



2PCS

C LEAF



2PCS


D CROSSBAR



1PC

B2 (BOX 2)

E PEDESTAL COLUMN



4PCS

F BASE



2PCS

HARDWARE IDENTIFICATION

Z-B1 (BOX 1) - HARDWARE PACK IS LOCATED IN 104601(B1)

1 THREADED BOLT
(Ø5/16" x 100mm - RBW)



4PCS

2 BOLT
(Ø5/16" x 50mm - RBW)



24PCS

3 LOCK WASHER
(Ø5/16" x 2mm - RBW)



28PCS

4 FLAT WASHER
(Ø5/16" x 2mm - RBW)



28PCS

5 ALLEN WRENCH
(4 x 60mm - RBW)



1PC

6 HEX NUT
(Ø5/16" x 12mm - RBW)




4PCS

7 WRENCH
(12mm - RBW)




1PC


ITEM: **104601(B1&B2)**
ASSEMBLY INSTRUCTIONS
STEP 1




STEP 2



ITEM: **104601(B1&B2)**
ASSEMBLY INSTRUCTIONS
STEP 3




STEP 4




ITEM: **104601(B1&B2)**

ASSEMBLY INSTRUCTIONS

STEP 5




STEP 6




ITEM: **104601(B1&B2)**

ASSEMBLY INSTRUCTIONS

STEP 7




STEP 8 COMPLETE



ADJUSTABLE LEVELER



ITEM: **104601(B1&B2)**



Note: Dimension tolerance $\pm 5\%$

ASSEMBLY INSTRUCTIONS
COASTER FINE FURNITURE



Fine Furniture for every stage of life

104507DOK
Side Chair

ITEM: **104507DOK**



ASSEMBLY INSTRUCTIONS

ASSEMBLY TIPS:

1. Remove hardware from box and sort by size.
2. Please check to see that all hardware and parts are present prior to start of assembly.
3. Please follow attached instruction in the same sequence as numbered to assure fast and easy assembly.



WARNING !

1. Don't attempt to repair or modify parts that are broken or defective. Please contact the store immediately.
2. This product is for home use only and not intended for commercial establishment.



ASSEMBLY TIME

15 MINUTES


PARTS IDENTIFICATION

A SEAT AND BACK




1PC

B FRONT LEG



2PCS

C BACK LEG



2PCS

HARDWARE IDENTIFICATION

1 LONG BOLT
($\varnothing 5/16$ x 60mm - RBW)



4PCS

2 SHORT BOLT
($\varnothing 5/16$ x 50mm - RBW)



4PCS

3 LOCK WASHER
($\varnothing 5/16$ - RBW)




8PCS

4 FLAT WASHER
($\varnothing 5/16$ - RBW)



8PCS

5 ALLEN WRENCH
(M4 x 50 x 100mm - RBW)




1PC


ITEM: **104507DOK**
ASSEMBLY INSTRUCTIONS





STEP 1



STEP 2




STEP 3
COMPLETE



ITEM: **104507DOK**

COASTER
FINE FURNITURE



Note : Dimension tolerance $\pm 5\%$