ASSEMBLY INSTRUCTIONS MODEL: 72202

Important note:

- Place all wooden parts on a clean and smooth surface such as a rug or carpet to avoid scratching the parts.
- Kindly follow the assembly instructions step by step.
- Do not tighten all screws and bolts until the chair is fully assembled.

PARTS LIST				
NO	DESCRIPTION	SRETCH	QTY	
A	CHAIR BACK		1 Pc	
В	CUSHION		1 Pc	
С	BACK LEG		2 Pcs	
D	FRONT LEG		2 Pcs	

HARDWARE LIST				
NO	DESCRIPTION	SRETCH	QTY	
1	LONG BOLT	()	8 Pcs	
2	SHORT BOLT	()))))))))	4 Pcs	
3	SPRING WASHER	C	12 Pcs	
4	FLAT WASHER	0	12 Pcs	
5	ALLEN KEY		1 Pc	

