





YOSEMITE EXTENSION TABLE ASSEMBLY INSTRUCTIONS


<p>A. TABLE TOP 1PC</p> 	<p><u>EXTENSION TABLE ASSEMBLED</u></p> 
<p>B. EXTENSION 1PC</p> 	
<p>C. LEFT LEG 1PC</p> 	
<p>D. RIGHR LEG 1PC</p> 	
<p>F. RAILS LEFT 1PC</p> 	
<p>E. CROSSBAR 1PC</p> 	<p>G. RAILS RIGHT 1PC</p> 

HARDWARE ARE PACKED IN BOX

1	ALLEN BOLT M8 x 50 MM	14 PCS	2	ALLEN BOLT M8 x 70 MM	02 PCS	3	THREAD BOLT M8 x 46 MM	01 PC	4	WASHER M8	18 PC	5	WASHER M9	12 PC
														
6	HEXAGON NUTS M8	02 PCS	7	HALF MOON WASHER	02 PCS	8	ALLEN KEY (4MM)	01 PC	9	SPANNER (N13)	01 PC	10	HEXAGON NUTS M8	01 PC
														


TOOL REQUIRED

PHILLS HEAD SCREW
DRIVER NOT PROVIDED




STEP 1:

FASTEN THE LEG (C) TO THE TOP (A), WITH BOLTS (1) AND WASHERS (4),(5).






STEP 2:

FASTEN THE RAILS (F),(G) AND CROSSBAR (E) WITH BOLTS (1), THREAD BOLT (3) AND WASHERS (4), HEXAGON NUTS (6).






STEP 3:

ATTACH THE UNIT TO THE TABLE TOP (A), FASTEN WITH BOLTS (1),(2) AND WASHERS (4),HEXAGON NUTS (6), HALF MOON WASHER (7).
WASHERS (4),HEXAGON NUTS (6), HALF MOON WASHER (7).





STEP 4:

FASTEN THE LEG (D) TO THE TABLE, WITH BOLTS (1), WASHERS (4),(5),HALF MOON WASHER (7).




STEP 5:





UNLOCK

STEP 6:

ATTACH EXTENSION (B) TO THE TABLE TOP (A).




STEP 7:



LOCK

STEP 8:



ASSEMBLY COMPLETE.