

ACR

REMOTE LEVEL CONTROL

AudioControl[®]
Making Good Sound Great[™]

IN-DASH CONVENIENCE

AUDIOCONTROL ACCESSORIES

ACR


REMOTE LEVEL CONTROL

Placement And Mounting of Optional Dash Remote:

The dash control may be mounted under the dash using its own bracket or through a custom hole in the dash. It should be within reach of the driver and in a spot where the LED is plainly visible.

Bracket Installation: The dash control mounts with two screws, which attach to the underside of the dashboard. Slide under the dash and place the dash control in its mounting position, mark the two mounting holes, drill pilot holes, and secure with two screws.

Custom Installation: For that custom, finished look, the dash control can be flush mounted directly on the dash-board (or anywhere else). Referencing the drawing right, disassemble the dash control from the mounting bracket. Drill a 9/32" (7 mm) hole in the dashboard for the control along with a 3/32" (2.3 mm) hole for the lock tab and a 1/8" (3 mm) hole(s) for the LED holder. Reassemble the dash control components on the dashboard.



Available Models

ACR-1
COMPATIBLE WITH
LC2i™, LC6i™, LC7i™,
Overdrive™ Plus, Matrix™ Plus,
6XS, The Epicenter®, LC-4.800™

ACR-2
COMPATIBLE WITH
LCQ-1™,
The Epicenter® Plus

ACR-3
COMPATIBLE WITH
DQ-61™, DQDX™, LC8i™
DM-608™, DM-810™, D-4.800™

AudioControl®
Making Good Sound Great™

22410 70th Ave West | Mountlake Terrace, WA 98043 USA
Phone 425-775-8461 | Fax 425-778-3166
www.audiocontrol.com

©2016 AudioControl. All rights reserved.
P/N 9120350 Rev B