





FEATURES:

BACK STYLE: Semi-attached inside back

DESIGN NOTE: Motorized recliners (-38 and -78) feature a USB charging port next to the activator switches

DIMENSIONS:		Length	Depth	Height	Inside Length	Seat Height	Seat Depth	Arm Height	Overall Length Fully Reclined	Wall Clearance Needed	Footrest Extension	
742-37	Manual Reclining Chair	32	41	41	22	22	20	25	72	4	21	
742-38*	Motorized Reclining Chair	32	41	41	22	22	20	25	71	4	21	
742-59	Swivel Glider Reclining Chair (shown)	32	41	41	22	22	20	25	70	12	21	
742-78*	Motorized Swivel Glider Reclining Chair	32	41	41	22	22	20	25	67	12	19	

^{*}Battery Pack Available











Activator switch features a USB charger

FEATURES:

BACK STYLE: Semi-attached inside back

DESIGN NOTE: Motorized recliners (-38 and -78) feature a USB charging port next to the activator switches

	DIMENSIONS:		Length	Depth	Height	Inside Length	Seat Height	Seat Depth	Arm Height	Overall Length Fully Reclined	Wall Clearance Needed	Footrest Extension
	742-37	Manual Reclining Chair	32	41	41	22	22	20	25	72	4	21
	742-38*	Motorized Reclining Chair	32	41	41	22	22	20	25	71	4	21
	742-59	Swivel Glider Reclining Chair (shown)	32	41	41	22	22	20	25	70	12	21
	742-78*	Motorized Swivel Glider Reclining Chair	32	41	41	22	22	20	25	67	12	19

*Battery Pack Available

