

Ipower Motomotion Furniture Speaker hook ups-recommended set up methods

1-2 units

All that is needed to hook up 1-2 units is the LED Bluetooth transmitter. See pic

This transmitter will have an optical cord that is highly recommended for this set up. Your TV must have one of the following audio out options. RCA out, Aux out, or **Optical out(recommended)**.

1. Connect the supplied wire to the Aux. RCA out, or the Optical out on your TV. We recommend Optical out as the best option.
2. Make sure your furniture is plugged in. The sofa and Loveseats have 2 power connectors, and the recliner has one. Make sure all are plugged in.
3. Turn the Bluetooth transmitter on and press the Bluetooth button until you see searching on the screen. Once you see searching, push the Bluetooth pairing button on your furniture until it starts to flash. On the LED screen you should see MOTOMOTION. Press in on the round dial button on the transmitter. You should hear "CONNECTING" from your furniture speakers. Then you should hear "CONNECTED". Once you hear this, you should get audio thru your furniture. If you do not hear CONNECTING, the switch on the transmitter on the item needs to be changed. If looking at the transmitter on the item, the switch should be LSF
4. If you have a second pc, do the same as above. **DO NOT TRY TO PAIR BOTH PCS AT THE SAME TIME.**
5. **Make sure to go into your TV settings and select optical out as your speaker option. If you have Optical Out Only and Optical Out Plus TV speakers, select Optical Out Plus TV speakers.**
6. There is typically a small Lag in audio from the TV to the Furniture. When using the speakers in your furniture, I would always turn the TV volume down. This will eliminate the LAG in the audio.
7. After the initial set up, your furniture should automatically connect to the transmitter. If for some reason it does not, just follow the above steps #3

3-4 units

In order to hook up a 3rd or 4th unit, you will need a 2nd Bluetooth transmitter and an Optical 1 to 2 splitter.

1. Hook the Optical Splitter into the Optical Out on the TV. Connect the Optical cable from Box 1 into the splitter and the Optical cable from box 2 into the Splitter.
2. Use the instructions above to hook up the 1st and 2nd pc. Make sure you DO NOT try to connect more than ONE pc at a time. After you have completed the above steps for piece 1 and 2, hit the Bluetooth button on box 2 and turn on piece 3 and hit the pairing button until it flashes. You will follow steps 3 above until it connects. If you have a 4th pc, turn it on and hit the pairing button on it until it flashes.
3. Make sure to complete 5 and 6 above once you have connected all pieces

If at any time your furniture does not connect to the transmitter, turn your furniture off and start the process above again.



Bluetooth Transmitter



Optical Splitter

MOTOMOTION BLUETOOTH CHECK OFF LIST

1-2 pcs

- 1 Hook up the Optical Cable to the TV and the Box.
- 2 Plug the Transmitter in and Power it up.
- 3 Make sure TV Audio Out is set to OPTICAL OUT.
- 4 Make sure Transmitter box has TX top left screen
- 5 Hit the 2nd Button-Bluetooth-until it says Searching
- 6 Turn the Item you want to Pair on.
- 7 You should hear Connecting. Hit the pair button till flashes
- 8 On the transmitter push in round button MOTOMEDIA
- 9 Item should then say Connected. You should have sound.

If you have a 2nd pc Follow steps 6-9 above. If the transmitter does not show another MotoMedia device, hit the 4th button on the transmitter and then it should connect.

MOTOMOTION BLUETOOTH CHECK OFF LIST

3-4pc

- 1 Hook the Optical Splitter to the Tv.
- 2 Hook both boxes up with optical and plug in for power.
- 3 Make sure both Transmitters have the TX on screen.
- 4 Keep one transmitter off and all product off.
- 5 Hit the 2nd Button-Bluetooth-until it says Searching
- 6 Turn the Item you want to Pair on.
- 7 You should hear Connecting. Hit the pair button till flashes
- 8 On the transmitter push in round button MOTOMEDIA
- 9 Item should then say Connected. You should have sound.

If you have a 2nd pc Follow steps 6-9 above. If the transmitter does not show another MotoMedia device, hit the 4th button on the transmitter and then it should connect.

To connect pc 3 and 4, start the above process over. Turn pc 1 and 2 down, not off. Turn the 2nd transmitter box on and repeat steps 5 thru 9 above. Pc 3 and 4 should connect the same as 1 and 2.