









Assembly Instruction for
COUNTER SIDE CHAIR
DMX100SC & DMX300SC & DMX400SC


- Caution: Please read instructions thoroughly before unpacking assembly parts. Sharp, exposed staple tips can cause injury, therefore, for your protection, please remove any exposed staples used in packing.
- 1. We recommend that you should assemble this product with the assistance of another person; this will make assembly easier, and will help to eliminate damage to the product or injury to persons during assembly.
 - 2. Be sure to check all packing materials carefully for small parts that may have come loose inside the carton during shipment.
 - 3. Please do not over tighten screws or bolts.
 - 4. Please put all parts on a non-abrasive floor before assembly, and follow the assembly steps to assemble your newly purchased product correctly and efficiently.

PART LIST FOR SIDE CHAIR			
No.	PART DESC.	CODE.	Q'TY
A	Pub Side Chair Back Frame	PDMX100SCBFR PDMX300SCBFR PDMX400SCBFR	1
B	Pub Side Chair Seat Frame With Cushion	PDMX100SCSEA PDMX300SCSEA PDMX400SCSEA	1
C	Pub Side Chair Left / Right Front Leg	PDMX100SCLRL PDMX300SCLRL PDMX400SCLRL	1 SET
D	Pub Side Chair Front Side Stretcher	PDMX100SCFRS PDMX300SCFRS PDMX400SCFRS	1
E	Pub Side Chair LSF / RSF Side Stretcher	PDMX100SCLRS PDMX300SCLRS PDMX400SCLRS	1 SET


HARDWARE LIST PACKED INSIDE BOX				
No.		HARDWARE DESC	CODE.	Q'TY
1		Allen bolt (Ø1/4**3-3/8")	PDMX100SCHW PDMX300SCHW PDMX400SCHW	4
2		Allen Bolt (Ø1/4**2-3/8")		4
3		Allen bolt (Ø1/4**1-5/8")		2
4		Spring washer (Ø1/4")		10
5		Flat washer (Ø1/4")		10
6		Screw (#4*1-1/2")		6
7		Allen key (Ø1/8")		1

 Only tighten all bolts when all bolts aligned with bolt inserts.

STEP:1



STEP:2



COMPLETED

