


**Warning :**

- Be sure to check all packing material carefully for small parts, which may have come loose inside the carton during shipment.
- To prevent possible scratches and damage, this furniture **MUST BE ASSEMBLED BY TWO PEOPLE** on a soft surface such as a blanket or carpet.




**37559**  
**Rush Seat Dining Bench 1in**


**Components and Hardware List**

<p><b>Bench Seat</b></p> <p><b>(A)</b> 1 pc.</p>	<p><b>Leg (Left)</b></p> <p><b>(B)</b> 2 pcs.</p>	<p><b>Middle Leg</b></p> <p><b>(C)</b> 2 pcs.</p>	<p><b>Leg (Right)</b></p> <p><b>(D)</b> 2 pcs.</p>		
<p><b>Long Stretcher</b></p> <p><b>(E)</b> 4 pcs.</p>	<p><b>Short Stretcher</b></p> <p><b>(F)</b> 3 pcs.</p>	<p><b>Flat Washer</b> 5/16" x 16*2mm</p> <p><b>(G)</b> 12 pcs.</p>	<p><b>Spring Washer</b> 5/16"</p> <p><b>(H)</b> 12 pcs.</p>	<p><b>Allen Head Bolt</b> 5/16"x 18x2- 1/8"</p> <p><b>(I)</b> 12 pcs.</p>	<p><b>5mm Allen Key</b></p> <p><b>(J)</b> 1 pc.</p>
				<p><b>#8x1-1/4 Screw</b></p> <p><b>(K)</b> 14 pcs.</p>	<p><b>Screw Driver</b> not included</p>


**STEP 1: Do not fully tighten the screws.**




STEP 2: Do not fully tighten the bolts.




STEP 3:




STEP 4: Do not fully tighten the bolts.



STEP 5:



STEP 6: Using the Allen key and a Phillips head screw driver, tighten all bolts, then tighten all screws.



Complete

