



Primo™


6304

Model # D444100420SHC1

ASSEMBLY INSTRUCTIONS NOTICE DE MONTAGE


**Place tracking label here
Placez l'étiquette de garantie ici**

- ** Please keep these instructions and have the product model # and part # available when requesting a service.
- ** Veuillez conserver ce notice de montage et avoir en main le numéro du modèle et de la pièce pour fin de service.



IMPORTANT NOTE

Do not use a power tool to assemble this product as it could damage the thread of the hardware and affect the solidity/durability of the product.



NOTE IMPORTANTE


Ne pas utiliser d'outil électrique pour assembler ce produit car cela pourra endommager le filet des quincailleries et par le fait même affecter la solidité/durabilité du produit.

ver. B / J.B / 03-20

6304

Model # D444100420SHC1

29139-01-6304-00003		29139-01-6304-00002	
A		B	
	1X		1X
29139-01-6304-00001			
C		D	
M6x30	4X	Ø16 / Ø6	E
		4X #4	1X



Step / Étape 1

Completely Assembled
Assemblage Completé

