



ASSEMBLY INSTRUCTIONS COASTER FINE FURNITURE



Fine Furniture for every stage of life

115515 Server

REVISION 0 : 04/27/2023

PAGE 1 OF 4

COASTERFURNITURE.COM

ITEM: 115515



ASSEMBLY INSTRUCTIONS


ASSEMBLY TIPS:

1. Remove hardware from box and sort by size.
2. Please check to see that all hardware and parts are present prior to start of assembly.
3. Please follow attached instructions in the same sequence as numbered to assure fast & easy assembly.



WARNING!

1. Don't attempt to repair or modify parts that are broken or defective. Please contact the store immediately.
2. This product is for home use only and not intended for commercial establishments.




ASSEMBLY TIME

30 MINUTES

PARTS IDENTIFICATION

A SERVER



1PC

HARDWARE IDENTIFICATION

1 WALL ANCHOR



1PC

2 TIGHTWIRE



1PC

3 LARGE WOOD SCREWS



1PC

4 SMALL WOOD SCREWS




1PC

ITEM:115515



ASSEMBLY INSTRUCTIONS

STEP 1




FURNITURE TIPPING RESTRAINT

WARNING


Injury may result from tipping furniture

This restraint is not a substitute for proper adult supervision.
This restraint may provide protection against tipping furniture.
Do not allow children to climb on furniture.
Failure to detach this restraint before moving furniture may result in injury and damage

ATTENTION: Anti tipping safeguard
Please install the Anti tipping hardware as shown in the drawing-this can help to prevent any tipping issues.



ITEM:115515



Note : Dimension tolerance $\pm 5\%$