



## TA54064

## **ASSEMBLY INSTRUCTION**


Page: 1/3
Date: Oct-31-2022



**P2** 




**P4** Table top




**x 1** 






**P5**) Leaf



**x** 1

**P3**) Center rail support

Stretcher



**1** Steel allen bolt, lock, flat washer




**x 20** 

**x 2** 

Steel allen open wrench





**x** 1





# TA54064 **ASSEMBLY INSTRUCTION**

Page: 2/3
Date: Oct-31-2022











#### TA54064


### **ASSEMBLY INSTRUCTION**

Page: 3/3

Date: Oct-31-2022

#### WHEN OPEN LEAVE PANEL

- -Open the lock of top panel (P1) as per (detail 'A'), then open the top panel arrow guide.
- -Put the leave panel (P5) to the top panel (P1) as per sketch 1, 2, then close the top panel arrow guide and close the lock. See detail 'B'



#### WHEN CLOSE LEAVE PANEL

- -Open the lock of top panel (P1) and the leave panel (P5) see detail 'C', then open the top panel arrow guide.
- -Remove the leaf panel (P5) out the top panel (P1) as per sketch 3, 4, then close the top panel arrow guide and close the lock. See detail 'D'.

