


HEATPUMP™ DRYER DIGITAL DIAL CYCLE & FABRIC CARE GUIDE

Dry differently, pump up efficiency for unmatched energy savings and gentle clothing care—with easy access to more than 20 drying cycles.



WHAT'S ON THE DIAL?

- Condenser Clean Indicator
- Wi-Fi Indicator
- Remote Start Indicator
- Control Lock Indicator
- Previous Screen Button
- Select Button

Choose one of the pre-loaded dry cycles or select special cycles for a wide range of load types.

DRY CYCLES	CYCLE DESCRIPTION
Normal	Mixed loads and cotton or linen fabrics
AI Dry	Optimizes cycle based on fabrics
Bedding	Bulky items, pillows, blankets or comforters
Small Load	Small or light items
Delicates	Lingerie, sheer or easily damaged fabrics
Towels	Designed for towels
Power Dry	A high-temperature dry cycle
Perm. Press	Minimizes wrinkles in "wrinkle-free" fabrics
Timed Dry	Lets you manually select the drying time
Drum Care	Use regularly to prevent odors

DRY CYCLES	CYCLE DESCRIPTION
Outerwear Refresh	Restores water-repellent treatment on outerwear
Shrinkage Relief	Optimizes cycle settings to reduce shrinkage
Bedding Refresh	Warms and fluffs up blankets
Air Dry	Tumble dries heat-sensitive items
Quick Dry	Small loads
Heavy Duty	Extra drying for heavier fabrics
Active Wear	Special or treated fabrics for sports or outerwear
Down Jacket Refresh	Helps restore loft to down jackets
Easy Ironing	Leaves clothes slightly damp for easy ironing
Silent Dry	Reduces sounds made during drying
Rainy Days	Dries damp clothes
Condenser Care	Additional condenser cleaning
Wrinkle Prevention*	Prevents wrinkles by tumbling clothes after the cycle
Rack Dry*	Dries items that should not be tumbled (install the rack)
Pet Care**	Use dedicated filters and drying balls



USES UP TO 65% LESS ENERGY WITH EVERY LOAD†
Compared to conventional vented dryers, this LG HeatPump™ dryer uses less energy to dry every load and is recognized as the Most Efficient of ENERGY STAR® 2024.



GO-ANYWHERE VENTLESS DESIGN
Ventless design can be installed almost anywhere, with a modern look that elevates any room. It's also easy to install and is virtually maintenance free.


*Indicates a bonus cycle you can download using the ThinQ® app on your smartphone.
**Indicates a bonus cycle you can download using the ThinQ UP™ app on your smartphone.

†When compared with conventional vented dryer DLE3400, based on Intertek testing in normal cycle with Energy Saver option, 8.45 lb. DOE standard load with 57.5% initial moisture content (September 2023).

Intuitive dial control gives you more of what you need with each turn, from descriptions of each setting and helpful prompts to status updates and remaining cycle time.

GET LAUNDRY DAY DIALED IN—IT'S EASY

Load, set and go—laundry day is just that easy with LG's LCD dial and touch panel.



1

POWER IT ON

Touch Power to turn on your LG HeatPump™ dryer—you'll be greeted with a tune and friendly "Hello."

2

TURN THE DIAL

Rotate the dial to choose from 10 pre-loaded cycles or touch Options to edit, remove or add cycles.

3

PRESS START

Touch and hold Start to begin the selected cycle. After sensing the load, the dial will show remaining cycle time.

COMPLETELY CUSTOMIZE YOUR CYCLE

Modify any cycle by using the touch panel to change settings like temperature, dry level and dry time to your liking. You can delay the start of a load and add options like Wrinkle Care.

MODIFY ANY CYCLE

Press pads such as Dry Mode, Dry Level or Dry Time to make adjustments to the selected cycle before you hit Start.

ADD OTHER OPTIONS

Options for each cycle will light up on the touch panel—press the one you want and then make selections on the dial.

GO BACK OR SELECT

Press the check mark on the dial to confirm your choice or hit the back button to see the previous screen.