


Progressive® ASSEMBLY INSTRUCTION








furniture Item No: D834-95








Description: COUNTER TABLE & 3 STOOLS




IMPORTANT NOTE :

- Place all wooden parts on a clean and smooth surface such as a rug or carpet to avoid the parts from being scratched.
- Check to be sure that you have all parts and hardware.
- Remove all wrapping materials, including staples & packing straps before you start to assemble.
- Do not tighten all screws/bolts until all completely assembled.
- Keep all hardware parts out of reach of children.

PARTS LIST			
NO.	COMPONENT		QTY.
1	TABLE LEG ❶		1 PCS
2	TABLE LEG ❷		1 PCS
3	TABLE LEG ❸		2 PCS
4	TABLE TOP		1 PCS
5	SIDE STRETCHER		2 PCS
6	REAR STRETCHER		1 PCS
7	SCALLOPED APRON		4 PCS


HARDWARE LIST			
NO.	DESCRIPTION		QTY.
A	M4 x 110MM ALLEN KEY		1 PCS
B	M5 x 85MM ALLEN KEY		1 PCS
C	M6 x 40MM JCBC BOLT		8 PCS
D	M8 x 60MM JCBC BOLT		8 PCS
E	M8 x 14MM SPRING WASHER		8 PCS
F	M8 x 22MM FLAT WASHER		8 PCS
G	M4 x 45MM PAN HEAD SCREW		6 PCS

STEP 1




⚠ PLEASE LAY TABLE TOP ON SOFT, CLEAN SURFACE TO ASSEMBLE
USB POWER OUTLET CAN BE SET UP AT THE DIRECTION PREFERRED BY TURNING AROUND THE TABLE TOP


STEP 2



STEP 3



STEP 4




Progressive® ASSEMBLY INSTRUCTION

furniture

Item No: D834-95





Description: COUNTER TABLE & 3 STOOLS








IMPORTANT NOTE :


- Place all wooden parts on a clean and smooth surface such as a rug or carpet to avoid the parts from being scratched.
- Check to be sure that you have all parts and hardware.
- Remove all wrapping materials, including staples & packing straps before you start to assemble.
- Do not tighten all screws/bolts until all completely assembled.
- Keep all hardware parts out of reach of children.

▲ PARTS FOR EACH CHAIR


NO.	PARTS LIST COMPONENT	QTY.
1	SEAT CUSHION 	1 PCS
2	SHORT SIDE STRETCHER 	2 PCS
3	LONG FRONT/REAR STRETCHER 	2 PCS
4	LEGS 	4 PCS

NO.	HARDWARE LIST DESCRIPTION	QTY.
A	M4 x 60MM ALLEN KEY 	1 PCS
B	M6 x 45MM JCBC BOLT 	4 PCS
C	M6 x 13MM SPRING WASHER 	4 PCS
D	M6 x 19MM FLAT WASHER 	4 PCS
E	M4 x 45MM PAN HEAD SCREW 	8 PCS

STEP 1




STEP 2



⚠ DO NOT TIGHTEN ANY BOLTS UNTIL ALL PARTS ARE IN PLACE IN STEP 3

STEP 3



STEP 4

