

ASSEMBLY INSTRUCTIONS COASTER FINE FURNITURE



Fine Furniture for every stage of life

805926 *Writing Desk*

REVISION 0: 01/24/2022 REVISION 1: 05/17/2022

ASSEMBLY INSTRUCTIONS



ASSEMBLY TIPS:

- 1. Remove hardware from box and sort by size.
- 2. Please check to see that all hardware and parts are present prior to start of assembly.
- 3. Please follow attached instructions in the same sequence as numbered to assure fast & easy assembly.



WARNING!

- 1. Don't attempt to repair or modify parts that are broken or defective. Please contact the store immediately.
- 2. This product is for home use only and not intended for commercial establishments.



ASSEMBLY TIME

15 MINUTES

PARTS IDENTIFICATION

A	CENTER PANEL	1PC
В	LEFT SIDE PANEL	1PC
С	RIGHT SIDE PANEL	1PC
D	TOP PANEL	1PC
E	LEFT LEG FRAME	1PC
F	RIGHT LEG FRAME	1PC
G	SUPPORT BAR	3PCS
Н	CROSSBAR	2PCS
I	BOTTOM RAIL	1PC

NOTE:

Phillips head screw driver is required in the assembly process; however, manufacturer does not provide this item.

ASSEMBLY INSTRUCTIONS



ASSEMBLY TIPS:

- 1. Remove hardware from box and sort by size.
- 2. Please check to see that all hardware and parts are present prior to start of assembly.
- 3. Please follow attached instructions in the same sequence as numbered to assure fast & easy assembly.



WARNING!

- 1. Don't attempt to repair or modify parts that are broken or defective. Please contact the store immediately.
- 2. This product is for home use only and not intended for commercial establishments.

J	USB CABLE	1PC
K	ADAPTER	1PC

HARDWARE IDENTIFICATION

1	BOLT (M6 x 65mm - RBW)		10PCS
2	HEX HEAD SCREW (M7 x 60mm - RBW)		6PCS
3	SHORT BARREL NUT (M6 x 13mm - RBW)		2PCS
4	LONG BARREL NUT (M6 x 50mm - RBW)		4PCS
5	WOOD DOWEL (M8 x 30mm-WOOD)		10PCS
6	LONG FLAT HEAD SCREW (M4 x 38mm - RBW)	Denimo	14PCS
7	PAN HEAD SCREW (#8 x 1 1/4" - BLK)	Dunno	8PCS

NOTE:

Phillips head screw driver is required in the assembly process; however, manufacturer does not provide this item.

ASSEMBLY INSTRUCTIONS



ASSEMBLY TIPS:

- 1. Remove hardware from box and sort by size.
- 2. Please check to see that all hardware and parts are present prior to start of assembly.
- 3. Please follow attached instructions in the same sequence as numbered to assure fast & easy assembly.



WARNING!

- 1. Don't attempt to repair or modify parts that are broken or defective. Please contact the store immediately.
- 2. This product is for home use only and not intended for commercial establishments.

HARDWARE IDENTIFICATION


8	CAM NUT (9mm - RBW)		2PCS
9	CAM BOLT (24mm - RBW)		2PCS
10	WOOD PLUG (14.5ø)	Θ	10PCS
11	ALLEN WRENCH (100mm - BLK)		1PC
12	SHORT FLAT HEAD SCREW (M4 x 25mm - BLK)	Dame.	2PCS
13	MINI FIX CAP ((L) - BLK)		2PCS

NOTE:


Phillips head screw driver is required in the assembly process; however, manufacturer does not provide this item.



ASSEMBLY INSTRUCTIONS STEP 1





STEP 2



PAGE 5 OF 9

COASTERFURNITURE.COM









COASTERFURNITURE.COM

ASSEMBLY INSTRUCTIONS STEP 5




STEP 6






ASSEMBLY INSTRUCTIONS STEP 7




STEP 8







ASSEMBLY INSTRUCTIONS STEP 9




STEP 10 COMPLETE



COASTERFURNITURE.COM

PAGE 9 OF 9





Note: Dimension tolerance ±5%