

ASSEMBLY INSTRUCTIONS COASTER FINE FURNITURE



Fine Furniture for every stage of life

552101 SOFA

PAGE 1 OF 5

COASTERFURNITURE.COM

ITEM:552101 ASSEMBLY INSTRUCTIONS



ASSEMBLY TIPS:

- 1.Remove wood legs from sofa bottom and sort by size.
- 2. Please check to see that parts are present prior to start of assembly.
- 3.Please follow attached instruction in the same sequence as numbered to assure fast & easy assembly.



WARNING!

- 1.Don't attempt to repair or modify parts that are broken or defective. Please contact the store immediately.
- 2. This product is for home use only and not intended for commercial establishment.



ASSEMBLY TIME


6 MINUTES


PARTS IDENTIFICATION

| A BASE | 1PC |
|------------------|------|
| B WOOD LEG | 5PCS |
| C L BACK CUSHION | 1PC |
| D R BACK CUSHION | 1PC |




STEP 1








STEP 2




STEP 3 COMPLETE









Note: Dimension tolerance ±5%



ASSEMBLY INSTRUCTIONS COASTER FINE FURNITURE



Fine Furniture for every stage of life

552102 LOVESEAT

PAGE 1 OF 5

COASTERFURNITURE.COM

ITEM:552102 ASSEMBLY INSTRUCTIONS



ASSEMBLY TIPS:

- 1.Remove wood legs from sofa bottom and sort by size.
- 2. Please check to see that parts are present prior to start of assembly.
- 3.Please follow attached instruction in the same sequence as numbered to assure fast & easy assembly.



WARNING!

- 1.Don't attempt to repair or modify parts that are broken or defective. Please contact the store immediately.
- 2. This product is for home use only and not intended for commercial establishment.



ASSEMBLY TIME

6 MINUTES


PARTS IDENTIFICATION


| A BASE | 1PC |
|------------------|------|
| B WOOD LEG | 4PCS |
| C L BACK CUSHION | 1PC |
| D R BACK CUSHION | 1PC |



COASTERFURNITURE.COM

STEP 1







PAGE 3 OF 5



STEP 2




STEP 3 COMPLETE





COASTERFURNITURE.COM





Note: Dimension tolerance ±5%