# MADERA FULL/QUEEN BED ASSEMBLY INSTRUCTIONS



	ASSEMBL	YINSI
BOX#1		
A. HEADBOAR	RD	1 PC
L. HEAD RAIL		1 PC
M. RIGHT WIN	IG	1 PC
N. LEFT WING		1 PC
* * * * * * * * *	* *	° ° ° L
	0 0	


		HANDWANE FACKE	INDIVARE FACILID IN DOX#2		
	1	ALLEN BOLT(5/16"x1")	<b>Olimin</b>	4 PCS	
	2	ALLEN BOLT(5/16"x2")	O Daniman	12 PCS	
	3	ALLEN BOLT(5/16"x3")		4 PCS	
	4	THREADED BOLT(5/16"x4-1/4")		4 PCS	
	5	FLAT WASHER(5/16")		20 PCS	
	6	LOCK WASHER(5/16")		20 PCS	
	7	ALLEN KEY(5/16"x4")		1 PC	
	8	WRENCH(5/16"x1/2")		1 PC	
	9	DOWEL(3/8"x1-1/2")		4 PCS	
	10	MENDING PLATE	0 0	2 PCS	


HARDWARE PACKED IN BOX#2

#### B. RIGHT SIDE RAIL 1 PC 1 PC C. LEFT SIDE RAIL 1 PC D. FOOTBOARD E. SLAT 26 PCS F. CENTER SLAT SUPPORT 1 PC G. SIDE RAIL SLAT CLIP 26 PCS H. CENTER SUPPORT SLAT CLIP **13 PCS** J. HEADBOARD/FOOTBOARD LEG 4 PCS K. SLAT SUPPORT LEG 2 PCS

Μ

BOX#2





 $\langle \bigcirc \rangle$ 

4 PCS








UPDATED:JUNE 20TH, 2022


HEX NUT(5/16"x12MM)


11




















### **STOP**

- IF USING BED WITH AN ADJUSTABLE MATTRESS BASE, SKIP STEPS 8, 9, 10,& 11 AND REFERENCE APPENDIX A: ADJUSTABLE MATTRESS BASE ASSEMBLY SUPPLEMENT.
- IF USING BED FRAME WITH STANDARD BOX SPRING OR FOUNDATION, CONTINUE TO STEP 8.









# INSTRUCTIONS FOR ADJUSTING LEVELERS:

Position the bed in your space and locate the leveler under each leg support (K).


Turn the leveler counter-clockwise to extend the leveler and clockwise to retract it.

Adjust each leveler until each leg support is applying equal, upward pressure on the bed support slat.

UPDATED:JUNE 20TH, 2022

## MAINTENANCE INSTRUCTIONS:

- Remove box spring and mattress before moving your bed.
- Lift your bed when moving it.
   Dragging can damage the leg support.
- Readjust levelers after moving your bed.



# MADERA FULL/QUEEN BED ASSEMBLY INSTRUCTIONS



APPENDIX A:ADJUSTABLE MATTRESS BASE ASSEMBLY SUPPLEMENT

AN ADJUSTABLE MATTRESS BASE IS A FREESTANDING MATTRESS SUPPORT THAT SITS WITHIN THE PERIMETER OF THE BED FRAME.

IF USING THIS BED FRAME WITH A STANDARD BOX SPRING OR FOUNDATION THESE INSTRUCTIONS DO NOT APPLY.

PRE-ASSEMBLED SIDE RAIL CLEATS OBSTRUCT ADJUSTABLE BASE INSTALLATION AND OPERATION. FOLLOW THESE INSTRUCTIONS TO REMOVE THEM.



### **WARNING!**


SIDE RAIL CLEATS ARE HELD IN PLACE USING PHILLIPS HEAD SCREWS. ONCE THEY ARE REMOVED THE USER WILL NOT BE ABLE TO SAFELY RE-INSTALL THE SIDE RAIL CLEATS FOR FUTURE USE WITH A STANDARD BOX SPRING OR FOUNDATION.

### THE FOLLOWING PARTS ARE NOT REQUIRED FOR ADJUSTABLE MATTRESS BASE INSTALLATION:

E. SLAT	26 PCS
F. CENTER SLAT SUPPORT	1 PC
G. SIDE RAIL SLAT CLIP	26 PCS
H. CENTER SUPPORT SLAT CLIP	13 PCS
K. SLAT SUPPORT LEG	2 PCS

### STEP 1:

USE A PHILLIPS HEAD SCREWDRIVER (NOT PROVIDED) TO UNSCREW THE PHILLIPS SCREWS AND REMOVE THE PRE-ASSEMBLED SIDE RAIL CLEATS.



UPDATED:JUNE 20TH, 2022

# **MADERA** C.KING/E.KING BED



BOX#2

8 PCS

14 PCS

4 PCS

4 PCS

26 PCS

26 PCS

1 PC


1 PC


4 PCS

2 PCS

4 PCS

ASSEMBLY INSTRUCTIONS				ONS L	
	BOX#1		HARDWARE PACKED IN BOX		
	A. HEADBOARD L. HEAD RAIL	1 PC 1 PC	1	ALLEN BOLT(5/16"x1")	
	M. RIGHT WING N. LEFT WING	1 PC 1 PC			
			2	ALLEN BOLT(5/16"x2")	
	* * * * * * *	0 0	3	ALLEN BOLT(5/16"x3")	© Janaania
	Α	L	4	THREADED BOLT(5/16"x4-1/4")	
		•	5	FLAT WASHER(5/16")	
	M	N	6	LOCK WASHER(5/16")	
	BOX#2		7	ALLEN KEY(5/16"x4")	
	B. RIGHT SIDE RAIL C. LEFT SIDE RAIL D. FOOTBOARD	1 PC 1 PC 1 PC	8	WRENCH(5/16"x1/2")	
	E. SLAT F. CENTER SLAT SUPPORT	39 PCS 2 PCS	9	DOWEL(3/8"x1-1/2")	
	G. SIDE RAIL SLAT CLIP H. CENTER SUPPORT SLAT CLIP J. HEADBOARD/FOOTBOARD	26 PCS 26 PCS LEG 4 PCS	10	MENDING PLATE	0
	K. SLAT SUPPORT LEG	4 PCS	11	HEX NUT(5/16"x12MM)	








UPDATED:JUNE 20TH, 2022
























### **STOP**


• IF USING BED WITH AN ADJUSTABLE MATTRESS BASE, SKIP STEPS 8, 9, 10,& 11 AND REFERENCE APPENDIX A: ADJUSTABLE MATTRESS BASE ASSEMBLY SUPPLEMENT.


K

• IF USING BED FRAME WITH STANDARD BOX SPRING OR FOUNDATION, CONTINUE TO STEP 8.









# INSTRUCTIONS FOR ADJUSTING LEVELERS:

Position the bed in your space and locate the leveler under each leg support (K).

Turn the leveler counter-clockwise to extend the leveler and clockwise to retract it.

Adjust each leveler until each leg support is applying equal, upward pressure on the bed support slat.



### MAINTENANCE INSTRUCTIONS:

- Remove box spring and mattress before moving your bed.
- Lift your bed when moving it.
   Dragging can damage the leg support.
- Readjust levelers after moving your bed.

## MADERA C.KING/E.KING BED ASSEMBLY INSTRUCTIONS



APPENDIX A:ADJUSTABLE MATTRESS BASE ASSEMBLY SUPPLEMENT

AN ADJUSTABLE MATTRESS BASE IS A FREESTANDING MATTRESS SUPPORT THAT SITS WITHIN THE PERIMETER OF THE BED FRAME.

IF USING THIS BED FRAME WITH A STANDARD BOX SPRING OR FOUNDATION THESE INSTRUCTIONS DO NOT APPLY.

PRE-ASSEMBLED SIDE RAIL CLEATS OBSTRUCT ADJUSTABLE BASE INSTALLATION AND OPERATION. FOLLOW THESE INSTRUCTIONS TO REMOVE THEM.



### **WARNING!**


SIDE RAIL CLEATS ARE HELD IN PLACE USING PHILLIPS HEAD SCREWS. ONCE THEY ARE REMOVED THE USER WILL NOT BE ABLE TO SAFELY RE-INSTALL THE SIDE RAIL CLEATS FOR FUTURE USE WITH A STANDARD BOX SPRING OR FOUNDATION.

### THE FOLLOWING PARTS ARE NOT REQUIRED FOR ADJUSTABLE MATTRESS BASE INSTALLATION:

E. SLAT	39 PCS
F. CENTER SLAT SUPPORT	2 PCS
G. SIDE RAIL SLAT CLIP	26 PCS
H. CENTER SUPPORT SLAT CLIP	26 PCS
K. SLAT SUPPORT LEG	4 PCS

### STEP 1:

USE A PHILLIPS HEAD SCREWDRIVER (NOT PROVIDED) TO UNSCREW THE PHILLIPS SCREWS AND REMOVE THE PRE-ASSEMBLED SIDE RAIL CLEATS.



UPDATED:JUNE 20TH, 2022