

# AMANA®


## **GAS RANGE**

### **MODELS:**

AGR4203MNB0 (Black)

AGR4203MNW0 (White)


# COOKTOP PARTS



# COOKTOP PARTS

<u>Illus. No.</u>	<u>Part No.</u>	<u>Description</u>	<u>Illus. No.</u>	<u>Part No.</u>	<u>Description</u>	<u>Illus. No.</u>	<u>Part No.</u>	<u>Description</u>
1		Literature Parts	6		Grate, Burner	17	98005663	Screw
	W11508839	Instructions, Installation		W10578251	Black	18	W10636339	Thermostat
	W11508817	Guide, Use and Care	7	98004722	Clip, Cooktop	19		Burner Cap, Auxiliary
	98007130	Tips, Safe Cooking (English)	8	98014544	Wire, Ground		W10169985	Black (Right Rear)
	W11565447	Sheet, Tech Cooktop	9	98013389	Bumper, Cooktop	20	W10515453	Assembly, Burner (6K) (Right Rear)
2	W10818512	Black	10	98006726	Screw (Black)	21	3400701	Screw
	W10818513	White		98005658	Screw (Stainless)	22	98006633	Screw
3		Panel, Manifold	11	98017461	Cap, Burner Black (Left Front, Left Rear, & Right Front)			FOLLOWING PARTS NOT ILLUSTRATED
	W11578458	Black	12	8534079	Screw, Ground	W10914402		Harness, Main
	W11578211	White	13	W10636224	Burner, Standard (Left Front, Left Rear, & Right Front)	98005896		Clip, Wire
4		Knob, Burner				3391018		Tie, Cable
	W11558936	Black	14	98007225	Screw	98015022		Bushing, Snap
	W11541410	White	15	W10613666	Bracket, Anti-Tip	W11492747		Insulation, Manifold
5		Knob, Oven	16	7101P485-60	Screw, Anti-Tip Kit			
	W10615601	Black						
	W10615600	White						


# BACKGUARD PARTS



# BACKGUARD PARTS

<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>	<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>
1		Endcap (Left Hand)	3		Backguard
	W10873109	Black		W11573719	Black
	W10873441	White		W11573720	White
		Endcap (Right Hand)	4	W10535746	Bracket, Console Mount
	W10873107	Black	5	98008545	Screw (Black)
	W10873438	White		98008544	Screw (White)
2	W10535815	Bracket, Rear	6	W10493726	Screw


# MANIFOLD PARTS



# MANIFOLD PARTS

<u>Illus. No.</u>	<u>Part No.</u>	<u>Description</u>	<u>Illus. No.</u>	<u>Part No.</u>	<u>Description</u>	<u>Illus. No.</u>	<u>Part No.</u>	<u>Description</u>
1	W10610297	Nut	7	W10146346	Screw	20	98017348	Orifice, Natural (9.5K)
2	W10543959	Assembly, Tubing (Left Front)	8	98013634	Screw			(Left Front, Left Rear, & Right Front)
	W10512770	Assembly, Tubing (Left Rear)	9	98005659	Screw			
	W10512771	Assembly, Tubing (Right Front)	10	W10650358	Oven Burner Asm-US Electronic		W10170506	Orifice, Natural (5K)  (Right Rear)
	W10514424	Assembly, Tubing (Right Rear)	11	W10493726	Screw	21	W11506321	Igniter, Hot Surface
3	W10122103	Bracket, Surface Burner  (Left Front, Left Rear, & Right Front)	12	W11562246	Harness, Switch	22	W11615438	Bracket, Valve
			13	98014893	Valve, Oven	23	W10512963	Tubing (Regulator to Oven Valve)
			14	W10822899	Clip, Ignitor	24	98007225	Screw
			15	W11509554	Valve, Saddle  (Left Front, Left Rear, & Right Front)	25	98007410	Bracket, Regulator
				W11509769	Valve, Saddle  (Right Rear)			FOLLOWING PARTS NOT ILLUSTRATED
4	W10622750	Cable, Spark (Black)	16	98017517	Screw			
5	W11281166	Java Tech Spark Module 4 POS	17	W11509619	Assembly, Manifold		W11557686	Kit, LP Conversion
6		Ignitor, Top	18	W10619922	Tube 3/8" Manifold To Reg			
	W11467380	Black	19	W10633327	Regulator			
	W11467378	Natural						

# CHASSIS PARTS






# CHASSIS PARTS

<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>	<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>	<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>
1	W10675411	Box, Flue	11	W11568988	Assembly, Oven Bottom	26	W11510655	Clip, Tubing
2	W10640762	Cord, Power	12	W10670197	Deflector, Oven	27	W10327222	Counter Support-Hinge
3	W10164110	Shield, Insulation	13	W10577312	Support, Side Panel	28	98006726	Screw (Black)
4		Panel, Side	14	W10520269	Rail, Base	29	W11579393	Spread, Flame (Bake)
	W10666212	Black (Left)	15	W10545322	Bracket, Manifold			FOLLOWING PARTS NOT ILLUSTRATED
	W10666211	Black (Right)	16	W11172758	Bracket, Foot		W11492324	Insulation, Wrap
	W10666176	White (Left)	17	W10549293	Safety Valve, Rear Cover		W11048974	Insulation, Back
	W10666141	White (Right)	18	98008545	Screw (Black)		W10613818	Insulation, Upper
5	98005502	Clip, Oven Botton	19	98005642	Clip, Therm Bulb		98004294	Wire Tie, Insulation
6	W10902689	Counterweight	20	W10554678	Back, Main			
7	98015363	Support, Rear	21	W10535778	Seal, Oven			
8		Frame, Front (Not Serviced)	22	W10493726	Screw			
9	W10650383	Foot Leveling Assembly (Front)	23		Liner, Oven (Not Serviced)			
10	W10058460	Foot, Leveling (Rear)	24	W10532560	Side Panel, Support			
			25	W11492823	Cover			


# OVEN AND BROILER PARTS



# OVEN AND BROILER PARTS

<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>	<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>	<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>
1	W10550642	Rack, Oven	8	98006726	Screw (Black)	13		Handle, Broiler Door
2	W10119413	Screw	9	W10446851	Liner, Broiler Drawer		W10535809	Black
3	98008545	Screw (Black)	10	W10682676	Back Cover, Broiler		W10498563	White
4	W10155121	Screw	11	W10216478	Insulation, Broiler Door	14	98004052	Bumper, Door
5	W10624273	Cover, Broiler Left	12		Panel, Broiler Door	15	W11620318	Baffle, Base
	W10624275	Cover, Broiler Right				16	98004993	Screw
6	W10647966	Hinge		W10874825	Black			
7	W10605426	Panel, Side		W10874828	White			

# DOOR PARTS



# DOOR PARTS

<u>Illus. No.</u>	<u>Part No.</u>	<u>Description</u>
1	98006726	Screw (Black)
	98006727	Screw (White)
2	W10292266	Seal, Inner Door
3	W10544145	Upper Trim, Oven Door
4		Trim, Side
	W11184558	Left
	W11184560	Right
5	W10146346	Screw

<u>Illus. No.</u>	<u>Part No.</u>	<u>Description</u>
6	W10535788	Hinge, Oven Door
7		Panel, Door
	W11647433	Black
	W11647558	White
8		Handle, Oven Door
	W11492899	Black
	W11492898	White
9	98008699	Screw
10	W10647533	Screw

<u>Illus. No.</u>	<u>Part No.</u>	<u>Description</u>
11		Badge
	W10846751	Black
	W10849465	White
12		Bracket, Glass Door Hold
	W10811550	Black
	W10823829	White
13	W11615629	Glass, Inner
14	W11569276	Handle, Support Bracket

# OPTIONAL PARTS (NOT INCLUDED)

## REFINISHING MATERIAL

<u>Illus. No.</u>	<u>Part No.</u>	<u>Description</u>
	242756	Oven Liner Touch Up Paint

## PAINT, TOUCH-UP (1/2OZ.)

<u>Illus. No.</u>	<u>Part No.</u>	<u>Description</u>
	72017	White
	511873	White Porcelain (2 oz.)

## PAINT, BULK (1 QT.)

<u>Illus. No.</u>	<u>Part No.</u>	<u>Description</u>
	799344	White (Uncut)

## INSULATION

<u>Illus. No.</u>	<u>Part No.</u>	<u>Description</u>
	261514	Insulation (1-1/2 x 24 x 120 in)
	240132	Insulation (2-1/2 x 22 x 120 in)

## PAINT, PRESSURIZED SPRAY (12 OZ.)

<u>Illus. No.</u>	<u>Part No.</u>	<u>Description</u>
	350930	White
	285006	Black

## MISCELLANEOUS

<u>Illus. No.</u>	<u>Part No.</u>	<u>Description</u>
	98012220	Kit, Door Pin