ASSEMBLY INSTRUCTIONS


Model: B8032DT-WHT/BLK + D9026DC-GRY

B8032DT-BLK+ D9026DC-SIL

Description : Dining Table + Dining Chair


Thank you for purchasing this quality product. Be sure to check all packing materials carefully for small parts, that may have come loose inside the carton during shipment

PART LIST : TABLE				HARDWARE LIST					
No	Description	Diagram	Quantity	PACKED IN INSIDE TABLE					
				No	Description	Diagram	Size	Quantity	
A	Table		1 pc	1	JCBB Bolt		M8 x 60mm	8 pcs	
				2	Spring Washer		5/16"	8 pcs	
	Leg		4 pcs	3	Flat Washer		5/16"IDx22mmOD	8 pcs	
В				4	Allen Key		M5 x 65mm	1 pc	




COMPLETE ASSEMBLY

STEP 1: Attach Table Dining Top (A) at soft surface



STEP 2: Attach Leg Post (B) at Table Marble Top (A)with Flat Washer (3), Spring Washer (2) and JCBB Bolt (1) and tighten with Allen Key (4).




2 OF 2

ASSEMBLY INSTRUCTIONS

Model :B8032DT-WHT/BLK + D9026DC-GRY B8032DT-BLK+ D9026DC-SIL **Description : Dining Table + Dining Chair**

Thank you for purchasing this quality product. Be sure to check all packing materials carefully for small parts, that may have come loose inside the carton during shipment


PART LIST : CHAIR				HARDWARE LIST						
No	Description	Diagram	Quantity	PACKED IN INSIDE CHAIR						
A	Back Rest Front Leg		1 pc 2 pcs	No	Description	Diagram	Size	Quantity		
				1	JCBB Bolt		M8 x 80mm	4 pcs		
				2	JCBB Bolt		M8 x 60mm	4 pcs		
В				3	Spring Washer		5/16 "	8 pcs		
	Cuhsion Seat		1 pe	4	Flat Washer		5/16"IDx22mmOD	8 pcs		
С				5	Allen Key		M5 x 65mm	1 pc		



COMPLETE ASSEMBLY

1 OF 2

STEP 1: Align the cuhsion seat (C) to the Back Rest (A) by secure with JCBB Bolt (1), Spring Washer (3) & flat washer (4) and tighten them with Allen Key (5) (DO NOT TIGHTEN BOLTS DURING THIS STEPS)



STEP 2: Align Front Leg (B) into cusion seat (C) and fix with JCBB Bolt (2), Spring Washer (3), Flat Washer(4) tighten them with Allen Key(5) as shown.

