

ASSEMBLY INSTRUCTIONS COASTER FINE FURNITURE



Fine Furniture for every stage of life

504954
OTTOMAN

REVISION 0 : 09/08/2025

ITEM: 504954



ASSEMBLY INSTRUCTIONS


ASSEMBLY TIPS:

1. Remove hardware from box and sort by size.
2. Please check to see that all hardware and parts are present prior to start of assembly.
3. Please follow attached instructions in the same sequence as numbered to assure fast & easy assembly.



WARNING !

1. Don't attempt to repair or modify parts that are broken or defective. Please contact the store immediately.
2. This product is for home use only and not intended for commercial establishments.




ASSEMBLY TIME

5 MINUTES

PARTS IDENTIFICATION

A. OTTOMAN



1PC

B. LEG




4PCS


ITEM: 504954
ASSEMBLY INSTRUCTIONS




STEP 1



STEP 2



ITEM: 504954
ASSEMBLY INSTRUCTIONS



Note: Dimension tolerance $\pm 5\%$

