
Model: U7068 Chair Description: Power Recliner With LED



Model: U7068 Chair Description: Power Recliner With LED


	PARTS LIST				PARTS LIST				
NO.	DESCRIPTION	SKETCH	QTY	NO.	DESCRIPTION	SKETCH	QTY		
Α	SEAT BODY		1 PC	С	LEFT EAR		1 PC		
В	BACK REST		1 PC	D	RIGHT EAR		1 PC		

HARDWARE LIST				HARDWARE LIST			
NO.	DESCRIPTION	SKETCH	QTY	NO.	DESCRIPTION	SKETCH	QTY
E	ADAPTER		1 PC				


Model: U7068 Chair Description: Power Recliner With LED

Thank you for purchasing this quality product. Be sure to check all packing material carefully for small parts that may have come loose inside the carton during shipment

Step 1: Attach the back rest (B) to seat body (A) as shown below diagram



Step 2: Attach the left ear (C) & the right ear (D) to the back rest (B) as shown below diagram




3 OF 4

Model: U7068 Chair Description: Power Recliner With LED

Thank you for purchasing this quality product. Be sure to check all packing material carefully for small parts that may have come loose inside the carton during shipment


Use the adapter (E) to connect with power, then open the footrest by pressing the power button on/off



Model: U7068 Loveseat

Description: Power Console Reclining Loveseat

With LED And USB



Model: U7068 Loveseat

Description: Power Console Reclining Loveseat With LED And USB

	PARTS LIST				PARTS LIST				
NO.	DESCRIPTION	SKETCH	QTY	NO.	DESCRIPTION	SKETCH	QTY		
A	SEAT BODY		1 PC	D	CONSOLE BACK REST		1 PC		
В	LEFT BACK REST		1 PC	E	LEFT EAR		1 PC		
С	RIGHT BACK REST		1 PC	F	RIGHT EAR		1 PC		


HARDWARE LIST				HARDWARE LIST			
NO.	DESCRIPTION	SKETCH	QTY	NO.	DESCRIPTION	SKETCH	QTY
G	ADAPTER		1 PC				

Model: U7068 Loveseat


Description: Power Console Reclining Loveseat With LED And USB

Thank you for purchasing this quality product. Be sure to check all packing material carefully for small parts that may have come loose inside the carton during shipment

Step 1: Attach the left back rest (B), the midle (D) & the right back rest (C) to the body seat (A) as shown below diagram.



Step 2: Attach the left ear (E) to the left back rest (B), attach the right ear (F) to the right back rest as shown below diagram



Model: U7068 Loveseat

Description: Power Console Reclining Loveseat With LED And USB

Thank you for purchasing this quality product. Be sure to check all packing material carefully for small parts that may have come loose inside the carton during shipment

Use the adapter (G) to connect with power, then open the footrest by pressing the power to open/close


Use the adapter (G) to connect with power, then open the footrest by pressing the power to open/close

Off On USB Type C

Press the button close/open to open or close the footrest as shown below diagram

Model: U7068 Sofa

Description: Power Reclining Sofa With Drop Down Table, Wireless Charger, LED And USB



Model: U7068 Sofa

Description: Power Reclining Sofa With Drop Down Table, Wireless Charger, LED And USB

Thank you for purchasing this quality product. Be sure to check all packing material carefully for small parts that may have come loose inside the carton during shipment

	PARTS LIST				PARTS LIST				
NO.	DESCRIPTION	SKETCH	QTY	NO.	DESCRIPTION	SKETCH	QTY		
A	SEAT BODY		1 PC	D	RIGHT BACK REST		1 PC		
В	LEFT BACK REST		1 PC	E	LEFT EAR		1 PC		
С	MIDLE BACK REST		1 PC	F	RIGHT EAR		1 PC		

HARDWARE LIST				HARDWARE LIST			
NO.	DESCRIPTION	SKETCH	QTY	NO.	DESCRIPTION	SKETCH	QTY
G	ADAPTER		1 PC				


2 OF 5

Model: U7068 Sofa


Description: Power Reclining Sofa With Drop Down Table, Wireless Charger, LED And USB

Thank you for purchasing this quality product. Be sure to check all packing material carefully for small parts that may have come loose inside the carton during shipment

Step 1: Attach the left back rest (B), the midle back rest (C) & the right back rest (D) to the seat body A) as shown below diagram



Step 2: Attach the left ear (E) & the right ear (F) as shown below diagram




3 OF 5

Model: U7068 Sofa

Description: Power Reclining Sofa With Drop Down Table, Wireless Charger, LED And USB

Thank you for purchasing this quality product. Be sure to check all packing material carefully for small parts that may have come loose inside the carton during shipment



4 OF 5

Model: U7068 Sofa

Description: Power Reclining Sofa With Drop Down Table, Wireless Charger, LED And USB

