









# ASSEMBLY INSTRUCTIONS

## 3900043/398236/3900106


Item	Parts	Picture	Qty
1	Front leg		2
2	Back leg		2
3	Chair		1

Item	Hardware	Picture	Qty
A	Bolt	 5/16"X2"	8
B	Spring washer		8
C	Flat washer		8
D	Allen wrench		1

Step 1: Remove the non-woven cover at bottom of the chair and take out the legs.



Step 2: Place the front legs (1) and back legs (2) onto the seat frame. Secure each leg using spring washer (B), flat washer (C), bolt (A). Tighten the bolts with an allen wrench (D).



Step 3: Turn the chair over and place it upright on a level surface.

