
ASSEMBLY INSTRUCTION T1-WA3247-W / T1-WA3247-X



- Please do not discard any of the packaging until you have checked all the parts and the packs of fittings.
- Before you begin to assemble your new piece of furniture, please check to ensure that all parts have been supplied.
- Follow instructions closely as deviation from them may void your warranty and present a possible safety risk.
- It is recommended that assembly is done on a soft surface like carpet to avoid any damage.
- Periodically check and re-tighten any fasteners. Wipe down all surface weekly with a clean cloth. Do not clean any surfaces with harsh abrasives or chemicals.

PARTS CHECK-LIST

CODE COMPONENT QTY

A TABLE TOP X1

B LEG X2

FITTING CHECK-LIST		
CODE	DESCRIPTION	ΔTY

01 JCBC SCREW



02 SPRING WASHER



03 FLAT WASHER




04 SPANNER




surface weekly with a clean cloth. Do not clean any surfaces with harsh abrasives or chemicals.

Assembly Legs



2. Extending the table




1. First, unlock the level pull bolt end of table



2. Both of center leaves must lift up together.



3. Flip open the extension table



4. Push bolt the end of table then unlock the level