

ASSEMBLY INSTRUCTIONS
COASTER FINE FURNITURE



Fine Furniture for every stage of life

800891
COMPUTER DESK

ITEM: 800891

ASSEMBLY INSTRUCTIONS


ASSEMBLY TIPS:

1. Remove hardware from box and sort by size.
2. Please check to see that all hardware and parts are present prior to start of assembly.
3. Please follow attached instructions in the same sequence as numbered to assure fast & easy assembly.



WARNING!








1. Don't attempt to repair or modify parts that are broken or defective. Please contact the store immediately.
2. This product is for home use only and not intended for commercial establishments.





ASSEMBLY TIME

30 MINUTES

PARTS IDENTIFICATION

A	TOP PANEL		1 PC	E	KEYBOARD SHELF		1 PC
B	LEFT SIDE PANEL		1 PC	F	LEFT DIVIDER PANEL		1 PC
C	RIGHT SIDE PANEL		1 PC	G	RIGHT DIVIDER PANEL		1 PC
D	BACK PANEL		1 PC				

HARDWARE IDENTIFICATION

Z							
NO	DESCRIPTION	FIGURE	Q'TY	NO	DESCRIPTION	FIGURE	Q'TY
1	GLUE 15g		1 PC	5	RAIL L = 300mm SR		1 SET
2	WOODEN DOWEL Ø 8x30mm		8 PCS	6	SCREW Ø 3.5x12.5mm SR		12 PCS
3	CAM LOCK Ø 15x12mm SR		8 PCS	7	ADJUSTMENT FEET Ø 35x17.2mm		4 PCS
4	CAM BOLT Ø 7x35.5mm SR		8 PCS	8	COUPLER		5 PCS


NOTE:

Phillips head screw driver is required in the assembly process; however, manufacturer does not provide this item.

ITEM:800891

Z



HARDWARE IDENTIFICATION

NO	DESCRIPTION	FIGURE	Q'TY	NO	DESCRIPTION	FIGURE	Q'TY
9	SCREW Ø 4.2x25.4mm RBW		10 PCS	12	BOLT Ø 6.2x18mm SR		1 PC
10	BOLT Ø 4.5x12mm SR		5 PCS	13	STICKER Ø 20mm		2 PCS
11	BOLT Ø 6.2x45mm SR		4 PCS				

Z5,Z6,Z7,Z8 not included in blister packaging.

STEP 1


Apply glue on all wooden dowels to ensure integrity of the structure.

**NOTE:**


Phillips head screw driver is required in the assembly process; however, manufacturer does not provide this item.

ITEM: **800891**


STEP 2



STEP 3




STEP 4




Apply glue on all wooden dowels to ensure integrity of the structure.

STEP 5




ITEM: **800891**

STEP 6




STEP 7

COMPLETE



ITEM: 800891



Note : Dimension tolerance $\pm 5\%$

ASSEMBLY INSTRUCTIONS
COASTER FINE FURNITURE



Fine Furniture for every stage of life

800892
DESK RETURN

ITEM: 800892

ASSEMBLY INSTRUCTIONS


ASSEMBLY TIPS:

1. Remove hardware from box and sort by size.
2. Please check to see that all hardware and parts are present prior to start of assembly.
3. Please follow attached instructions in the same sequence as numbered to assure fast & easy assembly.



WARNING!

1. Don't attempt to repair or modify parts that are broken or defective. Please contact the store immediately.
2. This product is for home use only and not intended for commercial establishments.




ASSEMBLY TIME

20 MINUTES


PARTS IDENTIFICATION

A TOP PANEL




1 PC

C RIGHT SIDE PANEL




1 PC

B LEFT SIDE PANEL



1 PC



D BACK PANEL



1 PC

Z

HARDWARE IDENTIFICATION

NO	DESCRIPTION	FIGURE	Q'TY	NO	DESCRIPTION	FIGURE	Q'TY
1	GLUE 15g		1 PC	7	BOLT Ø 6.2x45mm SR		4 PCS
2	CAM BOLT Ø 7x35.5mm SR		4 PCS	8	BOLT Ø 6.2x18mm SR		1 PC
3	CAM LOCK Ø 15x12mm SR		4 PCS	9	SCREW Ø 4.2x25.4mm RBW		10 PCS
4	ADJUSTMENT FEET Ø 35x17.2mm		4 PCS	10	WOODEN DOWEL Ø 8x30mm		4 PCS
5	COUPLER		5 PCS	11	STICKER Ø 20mm		1 PC
6	BOLT Ø 4.5x12mm SR		5 PCS				


Z4,Z5 not included in blister packaging.

NOTE:


Phillips head screw driver is required in the assembly process; however, manufacturer does not provide this item.

ITEM: **800892**


STEP 1



STEP 2




STEP 3




ITEM: **800892**


STEP 4



STEP 5




ITEM: **800892**



Note : Dimension tolerance $\pm 5\%$

ASSEMBLY INSTRUCTIONS
COASTER FINE FURNITURE



Fine Furniture for every stage of life

800893
CORNER DESK

ITEM: **800893**

ASSEMBLY INSTRUCTIONS


ASSEMBLY TIPS:

1. Remove hardware from box and sort by size.
2. Please check to see that all hardware and parts are present prior to start of assembly.
3. Please follow attached instructions in the same sequence as numbered to assure fast & easy assembly.



WARNING!

1. Don't attempt to repair or modify parts that are broken or defective. Please contact the store immediately.
2. This product is for home use only and not intended for commercial establishments.




ASSEMBLY TIME

15 MINUTES

PARTS IDENTIFICATION

A

TOP PANEL



1 PC

HARDWARE IDENTIFICATION

Z

NO	DESCRIPTION	FIGURE	Q'TY
1	LEG PLATE BLK		1 PC
2	METAL PLATE BLK		4 PCS
3	IRON PIPE Ø 60x734mm SR		1 PC
4	BOLT M 8x39mm BLK		1 PC
5	SCREW Ø 4x16mm RBW		20 PCS


Z1,Z2,Z3 not included in blister packaging.

NOTE:


Phillips head screw driver is required in the assembly process; however, manufacturer does not provide this item.

ITEM: **800893**


STEP 1




STEP 2



STEP 3



ITEM: **800893**



Note : Dimension tolerance $\pm 5\%$

ASSEMBLY INSTRUCTIONS
COASTER FINE FURNITURE



Fine Furniture for every stage of life

800891
COMPUTER DESK

ITEM: 800891

ASSEMBLY INSTRUCTIONS


ASSEMBLY TIPS:

1. Remove hardware from box and sort by size.
2. Please check to see that all hardware and parts are present prior to start of assembly.
3. Please follow attached instructions in the same sequence as numbered to assure fast & easy assembly.



WARNING!






1. Don't attempt to repair or modify parts that are broken or defective. Please contact the store immediately.
2. This product is for home use only and not intended for commercial establishments.





ASSEMBLY TIME

30 MINUTES

PARTS IDENTIFICATION

A	TOP PANEL		1 PC	E	KEYBOARD SHELF		1 PC
B	LEFT SIDE PANEL		1 PC	F	LEFT DIVIDER PANEL		1 PC
C	RIGHT SIDE PANEL		1 PC	G	RIGHT DIVIDER PANEL		1 PC
D	BACK PANEL		1 PC				

HARDWARE IDENTIFICATION

Z							
NO	DESCRIPTION	FIGURE	Q'TY	NO	DESCRIPTION	FIGURE	Q'TY
1	GLUE 15g		1 PC	5	RAIL L = 300mm SR		1 SET
2	WOODEN DOWEL Ø 8x30mm		8 PCS	6	SCREW Ø 3.5x12.5mm SR		12 PCS
3	CAM LOCK Ø 15x12mm SR		8 PCS	7	ADJUSTMENT FEET Ø 35x17.2mm		4 PCS
4	CAM BOLT Ø 7x35.5mm SR		8 PCS	8	COUPLER		5 PCS


NOTE:

Phillips head screw driver is required in the assembly process; however, manufacturer does not provide this item.

ITEM:800891

Z



HARDWARE IDENTIFICATION

NO	DESCRIPTION	FIGURE	Q'TY	NO	DESCRIPTION	FIGURE	Q'TY
9	SCREW Ø 4.2x25.4mm RBW		10 PCS	12	BOLT Ø 6.2x18mm SR		1 PC
10	BOLT Ø 4.5x12mm SR		5 PCS	13	STICKER Ø 20mm		2 PCS
11	BOLT Ø 6.2x45mm SR		4 PCS				

Z5,Z6,Z7,Z8 not included in blister packaging.

STEP 1

Apply glue on all wooden dowels to ensure integrity of the structure.




NOTE:


Phillips head screw driver is required in the assembly process; however, manufacturer does not provide this item.

ITEM: **800891**

STEP 2



STEP 3




ITEM: **800891**

STEP 4




COASTER®
FINE FURNITURE




Apply glue on all wooden dowels to ensure integrity of the structure.

STEP 5




ITEM: **800891**

STEP 6




STEP 7

COMPLETE



ITEM: 800891



Note : Dimension tolerance $\pm 5\%$

ASSEMBLY INSTRUCTIONS
COASTER FINE FURNITURE



Fine Furniture for every stage of life

800892
DESK RETURN

ITEM: 800892

ASSEMBLY INSTRUCTIONS


ASSEMBLY TIPS:

1. Remove hardware from box and sort by size.
2. Please check to see that all hardware and parts are present prior to start of assembly.
3. Please follow attached instructions in the same sequence as numbered to assure fast & easy assembly.



WARNING!

1. Don't attempt to repair or modify parts that are broken or defective. Please contact the store immediately.
2. This product is for home use only and not intended for commercial establishments.




ASSEMBLY TIME

20 MINUTES


PARTS IDENTIFICATION

A TOP PANEL




1 PC

C RIGHT SIDE PANEL




1 PC

B LEFT SIDE PANEL



1 PC



D BACK PANEL



1 PC

Z

HARDWARE IDENTIFICATION

NO	DESCRIPTION	FIGURE	Q'TY	NO	DESCRIPTION	FIGURE	Q'TY
1	GLUE 15g		1 PC	7	BOLT Ø 6.2x45mm SR		4 PCS
2	CAM BOLT Ø 7x35.5mm SR		4 PCS	8	BOLT Ø 6.2x18mm SR		1 PC
3	CAM LOCK Ø 15x12mm SR		4 PCS	9	SCREW Ø 4.2x25.4mm RBW		10 PCS
4	ADJUSTMENT FEET Ø 35x17.2mm		4 PCS	10	WOODEN DOWEL Ø 8x30mm		4 PCS
5	COUPLER		5 PCS	11	STICKER Ø 20mm		1 PC
6	BOLT Ø 4.5x12mm SR		5 PCS				


Z4,Z5 not included in blister packaging.

NOTE:


Phillips head screw driver is required in the assembly process; however, manufacturer does not provide this item.

ITEM: **800892**


STEP 1



STEP 2




STEP 3




ITEM: **800892**


STEP 4



STEP 5




ITEM: **800892**



Note : Dimension tolerance $\pm 5\%$

ASSEMBLY INSTRUCTIONS
COASTER FINE FURNITURE



Fine Furniture for every stage of life

800893
CORNER DESK

ITEM: **800893**

ASSEMBLY INSTRUCTIONS


ASSEMBLY TIPS:

1. Remove hardware from box and sort by size.
2. Please check to see that all hardware and parts are present prior to start of assembly.
3. Please follow attached instructions in the same sequence as numbered to assure fast & easy assembly.



WARNING!

1. Don't attempt to repair or modify parts that are broken or defective. Please contact the store immediately.
2. This product is for home use only and not intended for commercial establishments.




ASSEMBLY TIME

15 MINUTES

PARTS IDENTIFICATION

A

TOP PANEL



1 PC

HARDWARE IDENTIFICATION

Z

NO

DESCRIPTION

FIGURE

Q'TY

1

LEG PLATE
BLK



1 PC

2


METAL PLATE
BLK



4 PCS

3

IRON PIPE
Ø 60x734mm SR



1 PC

4

BOLT
M 8x39mm BLK



1 PC

5

SCREW
Ø 4x16mm RBW



20 PCS


Z1,Z2,Z3 not included in blister packaging.

NOTE:


Phillips head screw driver is required in the assembly process; however, manufacturer does not provide this item.

ITEM: **800893**


STEP 1




STEP 2



STEP 3



ITEM: **800893**



Note : Dimension tolerance $\pm 5\%$

ASSEMBLY INSTRUCTIONS
COASTER FINE FURNITURE



Fine Furniture for every stage of life

800894
MOBILE FILE CABINET

ITEM: **800894**

ASSEMBLY INSTRUCTIONS

ASSEMBLY TIPS:

1. Remove hardware from box and sort by size.
2. Please check to see that all hardware and parts are present prior to start of assembly.
3. Please follow attached instructions in the same sequence as numbered to assure fast & easy assembly.














WARNING!

1. Don't attempt to repair or modify parts that are broken or defective. Please contact the store immediately.
2. This product is for home use only and not intended for commercial establishments.

ASSEMBLY TIME

50 MINUTES





PARTS IDENTIFICATION

A	LEFT SIDE PANEL		1 PC	I	LEFT DRAWER SIDE PANEL		1 PC
B	RIGHT SIDE PANEL		1 PC	J	RIGHT DRAWER SIDE PANEL		1 PC
C	BOTTOM PANEL		1 PC	K	DRAWER FRONT PANEL		2 PCS
D	TOP PANEL		1 PC	L	DRAWER BACK PANEL		2 PCS
E	BACK BOARD		1 PC	M	LEFT DRAWER SIDE PANEL		2 PCS
F	BACK PANEL		2 PCS	N	RIGHT DRAWER SIDE PANEL		2 PCS
G	DRAWER FRONT PANEL		1 PC	O	DRAWER BOTTOM PANEL		3 PCS
H	DRAWER BACK PANEL		1 PC				

NOTE:

Phillips head screw driver is required in the assembly process; however, manufacturer does not provide this item.

ITEM: **800894**


Z				HARDWARE IDENTIFICATION			
NO	DESCRIPTION	FIGURE	Q'TY	NO	DESCRIPTION	FIGURE	Q'TY
1	GLUE 15g		1 PC	9	LOCK CASTER Ø 50mm		2 PCS
2	WOODEN DOWEL Ø 8x30mm		18 PCS	10	CASTER Ø 50mm		2 PCS
3	CAM LOCK Ø 15x12mm SR		16 PCS	11	WHEEL Ø 50mm		1 PC
4	CAM BOLT Ø 7x35.5mm SR		16 PCS	12	SCREW Ø 4x15mm SR		19 PCS
5	DRAWER SCREW Ø 4.2x35mm SR		12 PCS	13	STICKER Ø 20mm		3 PCS
6	GLIDES SCREW Ø 3x12mm SR		42 PCS	14	GLIDES L = 400mm WHT		3 SET
7	HANDLE L=120mm		3 PCS	15	IRON BAR Ø 9.5x402mm SR		2 PCS
8	HANDLE BOLT Ø 4x28mm SR		6 PCS				

Z7,Z8,Z9,Z10,Z11,Z12,Z14,Z15 not included in blister packaging.


NOTE:

Phillips head screw driver is required in the assembly process; however, manufacturer does not provide this item.

STEP 1




STEP 2




ITEM: **800894**

STEP 3




STEP 4




ITEM: **800894**

STEP 5




STEP 6






ITEM: **800894**

STEP 7




STEP 8









ITEM: **800894**

STEP 10



STEP 11
COMPLETE





Note : Dimension tolerance $\pm 5\%$