

KitchenAid® Flex Edge Beater Accessory for **Hand Mixer**

KHMFEB2

Available Finishes/Colours

KHMFEB2 Other

The Flex Edge Beater Accessory was designed for KitchenAid® Hand Mixers* to deliver 2X the surface area for faster, more thorough mixing,** and also reduces the need to scrape down sides of the bowl, when compared to metal beaters. *Fits KitchenAid® Hand Mixer models KHM3, KHM5, KHM6, KHM7, KHM9, and KHMB7, sold separately. **Compared to metal Turbo Beater II™ accessories based on cake batter.

Top Features

Quicker, More Thorough Mixing with Flex Edge **Beaters**

Designed for KitchenAid® Hand Mixers*

Dishwasher-Safe Beaters for Easy Clean Up

Manuals & Literature:



Use and Care Guide

