











Warning :

- Be sure to check all packing material carefully for small parts, which may have come loose inside the carton during shipment.
- To prevent possible scratches and damage, this furniture must be assembled on a soft surface such as a blanket or carpet.




92630 / 31 / 32
Button Tuft Uph Chair


Components and Hardware List

Chair Back  (A) 1 pc.	Seat Frame  (B) 1 pc.	Front Leg  (C) 2 pcs.	Allen Head Bolt $\varnothing 5/16"$ x 18 x 3-3/8"  (D) 4 pcs.	Allen Head Bolt $\varnothing 5/16"$ x 18 x 2-1/8"  (E) 4 pcs.
Allen Head Bolt $\varnothing 5/16"$ x 18 x 1-3/4"  (F) 2 pcs.	$\varnothing 5/16"$ Spring Washer  (G) 10 pcs.	$\varnothing 5/16"$ Flat Washer  (H) 10 pcs.	4mm Allen Key  (I) 1 pc.	


STEP 1: Remove Velcro strips on the seat frame to assemble the chair back and front legs.




STEP 2:



STEP 3:



STEP 4: Attach all Velcro strips to the seat frame.



COMPLETE