



## ASSEMBLY INSTRUCTIONS COASTER FINE FURNITURE



# 182175 COUNTER HEIGHT STOOL

ITEM:182175



## ASSEMBLY INSTRUCTIONS

### ASSEMBLY TIPS:

1. Remove hardware from box and sort by size.
2. Please check to see that all hardware and parts are present prior to start of assembly.
3. Please follow attached instructions in the same sequence as numbered to assure fast & easy assembly.




### WARNING!


1. Don't attempt to repair or modify parts that are broken or defective. Please contact the store immediately.
2. This product is for home use only and not intended for commercial establishments.

**ASSEMBLY TIME**


**15 MINUTES**




A SEAT 1PC



C LOWER LEG 1PC








B UPPER LEG 1PC



D FOOT 1PC

## HARDWARE IDENTIFICATION


| Z | HARDWARE NAME | FIGURE  | QTY  |
|---|---------------|---|------|
| 1 | BOLT          |  M6*25 | 1PC  |
| 2 | BOLT          |  M6*40 | 4PCS |
| 3 | BOLT          |  M6*45 | 4PCS |
| 4 | FLAT WASHER   |        | 4PCS |
| 5 | ALLEN WRENCH  |  M4    | 1PC  |

ITEM:182175


## ASSEMBLY INSTRUCTIONS




### STEP 1




### STEP 2



### STEP 3



### STEP 4



COASTERFURNITURE.COM

ITEM:182175

ASSEMBLY INSTRUCTIONS



COASTERFURNITURE.COM