




## AUDIO SYSTEM USER MANUAL



**Wireless LED:** When the LED is blinking, the controller is connected. When connected the LED will be on. The LED quickly blinks when starting the interconnection process.

**AUX LED:** When playing in AUX mode, the LED light will be on, the LED will blink when muted.

**Shutdown Light:** The LED light under the symbol is off when it is turned on, and the LED light under the symbol is on when it is turned off.

**Product features and description:**

This product is a speaker whose main function is to play audio.

### Link Instructions:

1. Input power: After the 29V power supply is turned on, the system starts. If the AUX cable is inserted on the top, the system enters the AUX function. If the AUX cable is not inserted on the top, the system enters the wireless function.
2. Turn on the mobile device to connect to the wireless function. Select "Audio System" in the mobile device connected to the speakers, and you can play audio from the mobile device.
3. Plug an AUX signal cable into the AUX port and the sound system will switch to AUX mode.
4. Two sets of speakers' factory settings will be dis-interconnected.
5. To use two sets of speakers' interconnection function, please only connect the mobile device to one set of speakers.
6. Start interconnection:

**Option A:** One wireless speaker already connected with the mobile device in advance: tap and hold "previous song" button in A speaker control panel. The "wireless" light in A speaker control panel will blink, within 180 seconds, tap and hold "previous song" button in B speaker control panel, the wireless light in both A and B speaker control panel will stop blinking and have voice prompt "connected" to indicate the two speakers are interconnected.

**Option B:** None of the speakers are connected to a mobile device in advance: tap and hold "previous song" button on A speaker control panel, the "wireless" light in A speaker will blink. Within 180 seconds, tap and hold "previous song" button in B speaker control panel, then A light will stop blinking and the voice prompt "connected" will be heard. B speaker wireless light will keep blinking until connected to a mobile device.

7. Stop interconnection function: tap and hold any of the "next song" button in A or B speaker control panel, two sets of speakers will dis-interconnect.

This device complies with part 15 of the FCC rules.

Operation is subject to the following two conditions:

- (1) This device may not cause harmful interference.
- (2) This device must accept any interference received, including interference that may cause undesired operation.