

ASSEMBLY INSTRUCTIONS COASTER FINE FURNITURE



Fine Furniture for every stage of life

923289

TABLE LAMP

ITEM: 923289

ASSEMBLY INSTRUCTIONS

ASSEMBLY TIPS:

- 1. Remove hardware from box and sort by size.
- 2.Please check to see that all hardware and parts are present prior to start of assembly.
- 3.Please follow attached instruction in the same sequence as numbered to assure fast & easy assembly.



WARNING!

- 1.Don't attempt to repair or modify parts that are broken or defective. Please contact the store
- 2. This product is for home use only and not intended for commercial establishment.

ASSEMBLY TIME


10 MINUTES

PARTS IDENTIFICATION

HARDWARE B FINIAL


1PC

A LAMP BODY



1PC

C SHADE



1PC

D HARP




1PC

ITEM: 923289

ASSEMBLY INSTRUCTIONS

STEP 1





STEP 2




TABLE LAMP: TYPE A LED BULB 9W

PAGE 3OF 4

